

## 7628063 COMPOSITE BASE REPAIR KIT

## Instructions

- 1. Area to be repaired must be clean, dry, and free of oil, grease, and residue.
- 2. Lightly sand repair area to break glaze on base material.
- 3. Remove all loose material from repair area.
- 4. Remove divider from adhesive packet and thoroughly mix the two components inside the packet. After the epoxy is thoroughly mixed, clip a corner of the packet and squeeze material onto a clean piece of paper.
- 5. Using the wood spatula, work the epoxy into the cracked area, filling voids with epoxy on both sides of the crack. Smooth epoxy with water-moistened finger or wet cloth. A small piece of metal or plastic covered with cellophane tape can be lightly clamped to each side of the repair area to achieve a smooth finish.

Manitowoc Ice, Inc.

2110 South 26<sup>th</sup> Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA

Telephone 920-682-0161, Fax - Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879

Web Site - www.manitowocice.com

8011083 Rev. 10/06/03