



## Installation Steps of Z bracket for In-swinging doors




Tighten the electromagnetic lock on the L bracket by using the fixing screw.




Assemble the Z bracket, and make sure that the Z bracket is adjustable.




Insert the guide pins into the armature plate.




Put one rubber washer between armature plate and the Z bracket.



Close the door. Measure the correct position by bringing the armature plate close to the contact surface of the electromagnetic lock.



Turn on the power of EM-Lock, and let the armature plate bonds to the EM-lock. Adjust the position between the Z bracket and the door frame.



Once the position is correct, use the screws to permanently mount the Z bracket on the door frame. This should be the last step.

## GIANNI INDUSTRIES, INC.

No. 13, Zhong Sing Road, Tu-Cheng Industrial Zone, Tu-Cheng City, Taipei, Taiwan 23678
Tel: 886-2 2267 7986 / Fax: 886-2 2267 9876
E-Mail: info@gianni.com.tw
Website: gianni.tw
Copyright 2008 Gianni industries, inc. All rights reserved.
DM-CA-Z-400N Ver. C Published on 2008.05.29

