




Magnet Grade	ValueA"	Option Brackets
300 LBS	38mm	L-150, L-EM150
600 LBS	42mm	L-300,L-10001ST
800LBS	48mm	L-750, L-350,L-400
1200 LBS	60mm	L-500,L-600



The new special styling bracket enables more aesthetic for the doors.








Application for the Electromagnet:

10001, 10004 (Double) Series

Fold the mounting template along the dotted line to a 90-degree angle. Close the door, place the template against the door and frame.



Compliant


Drill three holes in the door as indicated on the template.




Drill an 8 mm hole through door, from sexnut bolt side only, enlarge the 8mm hole to 16mm.




Drill an 6.8 mm dia. Hole and tap for M8x12.5 thread.




Drill an 8 mm hole thru door from sexnut bolt side of door, drill 12.7mmhole, 36mm in depth.




Use the Allen wrench to tighten the screws into the L bracket.



Turn on the power of EM-Lock, and let the armature plate bonds to the EM-lock. Adjust the position between the L bracket and the door frame.



Once the position is correct, use the screws to permanently mount the L bracket on the door frame.



Test the unit. Insert the antitamper caps into the mounting screw access holes.

## GIANNI INDUSTRIES, INC.

No. 13, Zhong Sing Road, Tu-Cheng Industrial Zone, Tu-Cheng City, Taipei, Taiwan 23678
Tel: 886-2 2267 7986 / Fax: 886-2 2267 9876
E-Mail: info@gianni.com.tw
Website: gianni.tw
Copyright 2008 Gianni industries, inc. All rights reserved.
DM-CA-EM-10001L Ver. C Published on 2008.05.30



