



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

#### Items Supplied >

- 1 - Swing Arm Skid Plate
- 4 - Bolt, Hex M8 x 20mm W/Patch

#### Application(s) >

HONDA TRX400EX

#### Instruction Manual >

50-1105

##### **Read your installation instructions completely before beginning.**

1. Remove the four M8 bolts from the stock swingarm protector. Remove the swingarm protector and wipe clean any dirt or debris from the area where the swingarm skidplate will mount.
2. Install the new Cobra swingarm skidplate under the swingarm with the M8 bolts provided.
3. Torque all bolts to appropriate values.
4. Recheck for loose bolts periodically and tighten as needed.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. A  
12/03

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

#### Items Supplied >

- 1 - Swing Arm Skid Plate
- 4 - Bolt, Hex M8 x 20mm W/Patch

#### Application(s) >

HONDA TRX400EX

#### Instruction Manual >

50-1105

##### **Read your installation instructions completely before beginning.**

1. Remove the four M8 bolts from the stock swingarm protector. Remove the swingarm protector and wipe clean any dirt or debris from the area where the swingarm skidplate will mount.
2. Install the new Cobra swingarm skidplate under the swingarm with the M8 bolts provided.
3. Torque all bolts to appropriate values.
4. Recheck for loose bolts periodically and tighten as needed.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. A  
12/03

**Anything's Possible.**