

INSTALL INSTRUCTIONS C-MCB-CV DUAL IN-DASH MICROPHONE CLIP BRACKET 1996-2007 FORD CROWN VICTORIA

TOOLS REQUIRED:

Ratcheting wrench
Sockets - 7/16", #10, #8

Screwdriver set
T-20 torx bit

Always!

- Read all instructions before installing any Havis-Shields Equipment Corp products.
- Disconnect the vehicle battery. Removing seat bolts on some vehicles may give the vehicles computer a false reading, causing a warning light on the instrument cluster. This requires the vehicles' computer to be reset with a vehicle diagnostics tool.
- **Check for obstructions (Wire, brake lines, fuel tank, etc.) before drilling any holes!**
- Use only hardware provided with install kit.
- For product support, visit the Install Instructions Section of our website at <http://havis.com/Installation/Installation.html>, email technicalsupport@havis.com or call 1-800-524-9900 and ask for technical support.



Police Package Crown Vic Dash.



Carefully remove trim panel



Remove hex head trim screws
shown above



Slide bracket between trim around radio and the trim panel previously removed



Replace screws previously removed



Re-attach trim panel



Install microphone clip brackets using #8 x 1/2" machine screws and hex nuts



Final assembly