ASSEMBLY INSTRUCTION　　TI　　ITEM#23174

1. Thread long support screws into holes of the mounting strip. Secure with 5/32" nut.
   The support screws should be long enough to protrude out the canopy when mounted.
2. Fasten mounting strip onto wall outlet box using two shorter screws .
3. Connect the wires from the fixture to the power supply wires outlex box.
   A. Twist together white wire from the fixture with white wire from outlet box. Cover with wire connector.
   B. Twist together black wire from the fixture with black wire from outlet box. Cover with wire connector.
   C. Wrap the ground wire from the fixture around the green ground screw located on the mounting strip.
      Tighten the green ground screw to the mounting strip.
4. Pass canopy through the support screws of mounting strip. Tighten ball nut onto the protruding support screws
   on mounting strip until the fixture body is held firmly to the wall.
5. Carefully unpack the glass shade from the box, and set the glass shade onto the socket, then install it into the frame.
6. Install the bulb (not included) into socket. Do not use greater than 60-watt bulb.
7. Restore electric power, and test your new fixture.

NOTE: Carefully remove the fixture from the carton. Check that all parts shown in package parts 1 and parts 2 are included.
Be carefully not to misplace any of the screws or wire connectors, which are needed for installing the fixture.

PACKAGE PART

Wire Connectors	2	Glass		4
Support Screw	2	Ball nut		2
5/32" Nut	2			
Green Ground Screw	1			
Outlet Box Screw	2			
Mounting strip	1			