

INSTALL INSTRUCTIONS C-VS-700-EXPL 2002-2005 FORD EXPLORER

TOOLS REQUIRED:

Phillips Screw Driver
Power Drill

1/8" Drill Bit

HARDWARE:

QTY: DESCRIPTION:

6 #10 x 3/4" Sheet metal screws

PART #:

GSM33195

INSTALLATION:

1. Mount Explorer C-VS Console:

- Place C-VS Console over top O.E.M console tight to dashboard.
- Mark (6) mounting holes.
- Drill 1/8" pilot hole through plastic trim.
- Mount VS-Console with #10 X 3/4" Sheet metal screws.

