



INSTALLATION INSTRUCTIONS WGI-F13 INTERIOR WINDOW GUARDS FOR 2002-2008 FORD EXPLORER

TOOLS REQUIRED:

Power drill	3/16" drill bit
Magic marker or pencil	Safety Goggles
Phillips screwdriver	Snips or cutter for plastic trim
1/8" drill bit	Ratchet wrench with 7/16" socket

HARDWARE FOR PASSENGER DOORS (WGI-F13-1 & WGI-F13-6):

18 #10 X 1/2" Sheet metal screws	GSM34150
----------------------------------	----------

INSTALLATION: (PASSENGER DOORS)

1. Hold window guard up to the window frame, and while pushing down against the door window frame, mark mounting hole locations. Remove guard and drill out mounting holes with 1/8" drill bit. Attach guards with #10 X 1/2" sheet metal screws.

FORD EXPLORER

WINDOW GUARD POSITIONS

MODEL WGI-F13

POSITION #1
DRIVERS SIDE PASSENGER DOOR
F13-1

POSITION #6
PASSENGER SIDE PASSENGER DOOR
F13-6