

INSTALL INSTRUCTIONS

C-STB-CHGR

2006-2008 DODGE CHARGER SPARE TIRE BRACKET

TOOLS REQUIRED:

Ratcheting Wrench

Metric/Standard Socket Sets

HARDWARE: *(Uses OEM hardware for mounting bracket)*

Always!

- ❖ Read all instructions before installing any Havis-Shields Equipment Corp products.
- ❖ Check for obstructions (Wire, brake lines, fuel tank, etc.) before drilling any holes!
- ❖ Use hardware provided with install kit.



Attach C-STB-CHGR mount, as shown above, using OEM hardware



Slide OEM bolt through jack stand, then through C-STB-CHGR.



Re-attach "wing" nut onto bolt and tighten.



Completed installation shown with optional C-TTB-CHGR slide out radio tray