



FACTORY STYLE INSTALLATION

(EXAMPLE: TOYOTA) SEE FIG. 2:

1. Remove factory radio dash panel to expose sub-dash.
2. Remove radio bracket assembly from sub-dash.
3. Remove and discard radio dummy panel attached to factory radio bracket assembly.
4. Install radio into bracket assembly using special

screws included with radio (see fig. 2)

CAUTION: Do not use longer screws or damage to internal parts of radio may occur

5. Re-install radio / bracket assembly after wiring radio.
6. Replace dash panel.

RADIO REMOVAL (IF NECESSARY)

1. Reverse installation procedure.

FIGURE 2

