

Read this before installing the hood: The following installation instructions assume that there is a solid surface behind the wall as outlined in the Operating and Installation instructions!
DO NOT install the hood directly to drywall or a plaster wall as wall anchors will not be able to support the weight of the hood!

