FLUSH MOUNT TEMPLATE

GARMIN

CUT ALONG BOLD LINE

OUTSIDE EDGE OF POCKET

3/8"

DRILL A HOLE FOR
A PLACE TO BEGIN CUTTING

Dashed lines indicate the actual
outline of the pocket. Cut along
bold line to provide clearance for
Detent Plate operation.

CUT ALONG BOLD LINE

TRIM ALONG DASHED LINE