1. PRODUCT DESCRIPTION 2. KIT CONTENTS 3. LOOSEN AND DISASSEMBLE TURNBUCKLE HCI+2 The Model HCI+2 2-foot "I-rail" extension is designed to be compatible with HOLD SCREWDRIVER IN the Model HCI-12 12-foot chain-drive "I-rail" used in commercial garage door TURNBUCKLE SLOT installations and in carriage house garage door installations. The 2-foot extension, **BOTTOM RAIL SECTION** when added to the 12-foot "I-rail", provides a 14-foot long rail for operating high-lift LOOSEN THE TWO TURNBUCKLE LOCKING NUTS 2-Foot Rail Extension The kit includes two "T-rail" sections that bolt together to form an "I-rail" and For Use with HCI-12 12-foot "I-beam" Rail **REINFORCING STRAPS (2)** connect to the main "I-rail" using two reinforcing straps. The kit also includes two short lengths of chain to extend the stock chain at the turnbuckle. **UNSCREW AND** REMOVE EACH Installation Instructions END FROM THE TURNBUCKLE TOP RAIL SECTION NOTE: ONE SIDE OF THE TURNBUCKLE IS LEFT-HAND THREAD, THE OTHER SIDE IS RIGHT-HAND THREAD USA & Canada (800) 421-1587 & (800) 392-0123 **EXTENSION CHAINS (2)** (760) 438-7000 - Toll Free FAX (800) 468-1340 www.linearcorp.com 4. REMOVE SPROCKET 5. REMOVE RAIL BOLT 6. IDENTIFY TOP AND BOTTOM EXTENSION RAILS 7. ALIGN REINFORCING STRAPS LINE UP SLOTS ON THE AFTER THE CHAIN IS LOOSENED, LOOSEN THE NUTS AND REINFORCING STRAPS REMOVE THE SPROCKET HOLDER REMOVE THE TWO END TOP RAIL SECTION REINFORCING STRAP #1 WITH THE SLOTS ON THE FROM THE END OF THE RAIL **BOLTS ON THE RAIL** STOCK I-RAIL 0 0 0 0 0 NOTE: BE SURE AND KEEP THE NUTS AND BOLTS, THEY WILL BE **BOTTOM RAIL SECTION USED AGAIN LATER** REINFORCING STRAP #2 NOTE: BOTTOM RAIL HAS NOTCH ON CORNER! 8. INSTALL FIRST TWO STRAP BOLTS 9. PLACE BOTTOM EXTENSION RAIL BETWEEN STRAPS 10. ALIGN TOP EXTENSION RAIL BETWEEN STRAPS 11. INSTALL REMAINING TWO STRAP BOLTS **INSTALL STRAPS ON BOTH** SIDES OF I-RAIL INSTALL THE LAST TWO BOLTS FIT BOTTOM RAIL SECTION TOP RAIL SECTION **INSTALL BOLT AND BOTTOM RAIL SECTION** AND NUTS THROUGH THE BETWEEN THE TWO NUT IN FIRST SLOT REINFORCING STRAP SLOTS REINFORCING STRAPS RAIL EDGES MUST LINE UP STOCK I-RAIL STOCK I-RAIL USE 1/4-20 x 13/16" BOLTS AND KEPS NUTS SUPPLIED BE SURE ALL THE SLOTS ARE ALIGNED FIT THE TOP RAIL SECTION INSTALL BOLT AND NUT BETWEEN THE STRAP ON RAIL EDGES MUST LINE UP IN THE SECOND SLOT BE SURE ALL THE THIS SIDE AND THE BOTTOM FOR SMOOTH TROLLEY SLOTS ARE ALIGNED **RAIL SECTION** OPERATION USE 1/4-20 x 13/16" BOLTS AND KEPS NUTS SUPPLIED NOTCH ON THE BOTTOM RAIL WILL BE ON THIS END, BUTTING UP TO THE NOTCH ON THE STOCK I-RAIL

