

## Virus Package

For a 75mL culture flask

1. Complex

Opti	900μL
PSPA <sub>2</sub>	3μg
PMD <sub>2</sub>	1.5μg
Our part	4.5μg
MegaTran 1.0 Transfection Reagent	27μL

2 Wait for 20 minutes and lentiviral vector is packaged.

**Reference: MegaTran Application Guide**