

Instruction Manual



Romak – 3 Dragunov 7.62x54R

WARNING:

Before using this firearm, read carefully and follow these instructions.

This instruction manual should always accompany the firearm and be transferred with it upon change of ownership.

Safety Guidelines

For Proper Operation and Handling of Your Dragunov Rifle.

1. Understand and follow all basic firearm rules of safe handling.
2. Keep the muzzle of your firearm pointed in a safe direction.
3. Keep firearm unloaded when not in use.
4. Be absolutely certain of your target and the backstop before proceeding to fire (Remember before pulling the trigger that this is a high power, long range weapon).
5. Before loading your firearm, examine the bore to make certain it is unobstructed. Firing a gun with any obstruction in the bore or even a heavy coating of oil or drops of water can cause the barrel to rupture upon firing, causing serious injury to the shooter and bystanders.
6. Never exclusively rely on your gun's safety. Please exercise good judgement.
7. Don't shoot at a hard surface or at water. A bullet may ricochet and travel in unpredictable directions with considerable velocity causing injury and damage to property.
8. Never handle a firearm without checking to make sure that it is unloaded.
9. In case of failure to fire, keep muzzle pointed in a safe direction for at least 30 seconds. After 30 seconds, remove the magazine and slowly open the action to retrieve the cartridge. Then properly dispose of the mis-fired round.
10. Always use eye and ear protection.

Loading & Operation

Loading Your Dragunov

1. Place bullet in the center of the magazine and depress downward (Repeat until the mag is full).
2. When the mag is loaded, (keeping the weapon pointed in a safe direction) place the front lip of your mag into the weapon until you feel it catch, then rotate the mag to the rear until the mag catch locks the mag into place.
3. While holding the firearm in a safe direction and all fingers away from the trigger, loop your finger over the bolt handle and firmly pull to the rear of the weapon until it can't go any further and then release it.
4. You have now chambered a round. Place your safety lever to the upper most position.
5. When you are ready to fire and you are sure of your target and what's behind it, drop your safety lever to the lower most position.
6. Aim at your target and pull the trigger.
Please Note: Once the trigger is pulled, the bullet is going out of the barrel. Nothing will bring it back.
PLEASE BE SURE OF YOUR TARGET.
7. To unload your weapon, start by removing the loaded magazine. Then pull the bolt handle back and look into the chamber. A good habit would be to pull the bolt at least 2 times, just to be sure.


Disassembling the Romanian Dragunov

1. Make sure that the weapon is **unloaded!**
2. Press in on Recoil Assembly Button (Figure 1).
3. Pull upward and remove the Receiver Cover (Figure 2).
4. Push Recoil Spring button in until it is clear of the catch, then remove to the rear.




5. Pull bolt Assembly to the rear and then lift up and back it out of the gas tube (Figure 3).
6. Slide bolt (Figure 4) to the rear of the bolt carrier, turn left to clear rotating lock, then slide out of the carrier to the front.

7. Raise Gas Tube Lever (Figure 5), located on the right side of the weapon below the rear sight.
8. Lift the Gas Tube (Figure 6) up and to the rear.




Your weapon is now disassembled as far as it should need to be for regular cleaning. Any further disassembly should be done by a skilled professional.

Safety Lever Operation



The Safety Lever on your Romak-3 is the same design as the standard AK-47. Simply slide the lever to the upper most position and it locks the trigger mechanism and also blocks the bolt from chambering a round. Slide the lever to the lower position to fire the weapon. *Note: Never completely rely on your weapon's safety. Always keep your weapon pointed in a safe direction.*

Exploded View



- | | |
|---------------------------|---------------------------------|
| 1. Recoil Spring Assembly | 8. Gas Port |
| 2. Receiver Cover | 9. 10 RD Mag |
| 3. Bolt Carrier w/Piston | 10. Safety Lever |
| 4. Bolt | 11. Mag Release |
| 5. Gas Tube Lever | 12. Trigger |
| 6. Gas Tube | 13. Rear Sight |
| 7. PSO-1 Scope | 14. Forearm Stock Release Lever |
| | 15. Front Sight Assembly |

You have just purchased a gun that is capable of shooting great distances. Please be responsible in this era of “blame the gun, not the shooter”. If you ever want your children or grandchildren to know the freedom of gun ownership, it rests in your hands.

**YOU ARE RESPONSIBLE
FOR YOUR ACTIONS!
HANDLE SAFELY & WITH CARE!**

Always keep your firearms locked up & out of reach of children & other unauthorized individuals.

TECHNICAL DATA

Romanian Dragunov Sniper Rifle

Caliber (mm)	7.62x54mm
Length (mm)	
Weapon	1,150
Barrel	625
Weight (kg/without site)	
Weapon	4.06
Empty Magazine (10Rd)	0.1
Loaded Magazine (10Rd)	0.318
Rifling	4x570mm
Surveyor's pole line (mm)	590
Rate of fire (RPM)	
Theoretical	30
Practical	8-10
Firing range by using rear sight (m)	1,200
Firing range by using telescope (m)	1,300
Bullet Speed (m/s)	830
Effective Range (m)	1,000
Maximum Range (m)	3,000
Ammunition Type	7.62x54mm
Magazine Capacity	5/10 Rds
Sight	
Field of view	6
Magnification	4x
Graduated Range (m)	800
Weight (kg)	0.65

- ◆ *Attractive Laminated Wood Stock*
- ◆ *4x Illuminated Scope w/ Battery*
- ◆ *Factory Installed Compensator*
 - ◆ *Trigger Lock w/2 Keys*
- ◆ *Cleaning Kit & Sling Included*