

## TOOLS for CC121 V1.5.1 for Windows

---

TOOLS for CC121 V1.5.1 for Windows consists of the following programs.

- USB-MIDI Driver V2.2.4 (Windows XP) / V3.0.4 (Windows Vista / Windows 7)
- Steinberg CC121 Extension V1.5.1

### Main Revisions and Enhancements

- The installer for TOOLS for CC121 has been modified. The TOOLS for CC121 Installer installs “USB-MIDI Driver” and “Steinberg CC121 Extension” at the same time. For instructions on installation, refer to the included Installation Guide.
- TOOLS for CC121 now supports Windows 7.

The other main fixes and enhancements for each program are explained below.

#### Steinberg CC121 Extension



V1.5.0 to V1.5.1

- Solved some minor problems.

### Legacy Updates

#### Steinberg CC121 Extension

V1.1.0 (32-bit) / V1.1.1 (64-bit) to V1.5.0

- Added a function so that you can now open and close the folder track or the automation track by pressing the CHANNEL SELECT [][] buttons simultaneously.
- Added the Operating Quick Control mode. This mode lets you operate the Quick Control functions on Cubase. You can also adjust or switch on/off the Sends in this mode.
- Improved the operability by increasing the resolution of the [F] (Frequency) knobs in the EQ sections. Update the CC121 Firmware to V1.50 or later.
- Solved the problem in which the Pan knob and the knobs of the EQ section could not adjust the corresponding parameter when an inactive project file was closed on Cubase.





V1.1.0 to V1.1.1 (64-bit only)

- Solved the problem in which the CC121 Extension (64-bit) might be installed to Cubase series (32-bit) if Cubase series (32-bit) has already been installed on your computer.

#### Attention

To prevent such a problem above, be sure to uninstall both CC121 Extension 32-bit and 64-bit before installing the CC121 Extension V1.1.1.

#### V1.0.1 to V1.1.0

- Now supports Cubase 5.
- Now supports Windows Vista 64-bit.
- Now the CC121 can control the tracks for Rewire channels.
- Holding the CHANNEL SELECT [][] buttons now changes the track from the current one to another.
- Improved the response speed of the [] (Play) button and [] (Record) button while the [JOG] button is turned on.

#### V1.0.0 to V1.0.1

- Now supports Nuendo 4.2.1.
- Solved some minor problems.