

reservant of the

DOSOVIES OCEUL


200

208 204-K CREATE AND MANAGE USERS AND VIEW AND EDIT PROPERTIES OF VIEW AND EDIT PROPERTIES OF WELCOME NETWORK SETUP DISKS AND VOLUMES | SERVICES USERS & GROUPS SHARES MANAGE 212-4 - 204-... 206 MANAGE AND OPTIMIZE DISKS, PARTITIONS AND VOLUMES. CLICK A LINK BELOW TO BEGIN. **Manage Directo**ry MANAGE VOLUMÉS GROUPS OF USERS. NETWORK SHARES. MANAGE GROUPS DIRECTORIES. 204-5 - 204-4 START, STOP, AND MANAGE SERVICES VIEW AND EDIT PROPERTIES OF DISKS VIEW AND EDIT PROPERTIES OF DISKS 212-2 212-1 204-3 MANAGE DEVICES MANAGE DISKS AND VOLUMES AND VOLUMES SERVICES MANAGE DISKS MANAGE VOLUMES 210 204-2 DISKS AND VOLUMES 204-1 205-2 -205-1 202 -

306.5


799.3

310



799.4

500~



719.5