



[Fig. 1]



[Fig. 2]

MAIN	11CH
SUB	39CH
RANDOM	ON
	SET TIME
	4 SECONDS

[Fig. 3]



[Fig. 4]

SET SWITCH TIME 1 MINUTE