



Illustrated Parts List

100600

Direct Overhead Valve

TYPE NUMBERS

0015, 0025, 0100, 0110, 0111, 0112,
0115, 0116, 0118, 0119, 0120, 0121,
0122, 0123, 0124, 0126, 0771.


TABLE OF CONTENTS











Air Cleaner	4
Blower Housing	5
Brake	5
Cam Gear	2
Carburetor	3
Carburetor Overhaul Kit	7
Controls	3
Crankcase Cover/Sump	3
Crankshaft	2
Cylinder	2
Cylinder Head	2
Electric Starter	6
Engine/Valve Gasket Sets	7
Exhaust	5
Flywheel	5
Fuel Supply	4
Governor Spring	3
Ignition	4
Lubrication	2
Piston/Rings/Connecting Rod	2
Rewind Starter	5

PRINTED IN U.S.A.





COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.










100600










1036 EMISSIONS LABEL

1058 OPERATOR'S MANUAL



100600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	793508	Cylinder Assembly	25	793519	Piston Assembly (Standard)	104	698536	Pin-Float Hinge
3	299819S	Seal-Oil (Magneto Side)			----- Note -----			Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.
4	793509	Sump-Engine			793518 Piston Assembly (.020" Oversize)			
5	793502	Head-Cylinder	26	793435	Ring Set (Standard)			
7	793455	Gasket-Cylinder Head			----- Note -----	105	698537	Valve-Float Needle
9	793439	Gasket-Breather			793517 Ring Set (.020" Oversize)			Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.
11	793447	Tube-Breather	27	691588	Lock-Piston Pin			
12	793445	Gasket-Crankcase (.015" Thick) (Standard)	28	298909	Pin-Piston (Standard)			
13	793451	Screw (Cylinder Head) (M8x71.0mm Long)	29	793510	Rod-Connecting			
15	691680	Plug-Oil Drain	32	691664	Screw (Connecting Rod) (1 3/32" Long)			
16	793426	Crankshaft Used on Type No(s). 0025, 0100, 0121, 0122, 0771.	32A	695759	Screw (Connecting Rod) (1 1/2" Long)	117	793466	Jet-Main (Standard)
		----- Note -----						Used on Type No(s). 0100.
		793615 Crankshaft Used on Type No(s). 0015, 0115, 0118, 0123.	33	793505	Valve-Exhaust	117A	793694	Jet-Main (Standard)
		793429 Crankshaft Used on Type No(s). 0110, 0111, 0124, 0126.	34	793504	Valve-Intake			Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.
		793616 Crankshaft Used on Type No(s). 0112, 0116, 0119, 0120.	35	793506	Spring-Valve (Intake)			
20	399781S	Seal-Oil (PTO Side)	36	793506	Spring-Valve (Exhaust)	118	793467	Jet-Main (High Altitude)
22	793450	Screw (Crankcase Cover/Sump) (40.5mm)	37	793473	Guard-Flywheel Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0118, 0119, 0121, 0122, 0123, 0124, 0126, 0771.			Used on Type No(s). 0100.
23	793489	Flywheel Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0119, 0121, 0122, 0123, 0124, 0126, 0771.	37A	794106	Guard-Flywheel Used on Type No(s). 0116, 0120.	118A	793695	Jet-Main (High Altitude)
23A	793619	Flywheel Used on Type No(s). 0116, 0120.	40	793503	Retainer-Valve			Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.
		----- Note -----	51	692555	Gasket-Intake			
		793682 Flywheel Used on Type No(s). 0118.	58	697316	Rope-Starter (88 5/8" Long)	121	793622	Kit-Carburetor Overhaul
24	222698S	Key-Flywheel	60	281434S	Grip-Starter Rope			Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.
			75	691736	Washer (Flywheel)			
			78	793480	Screw (Flywheel Guard) (M8x14.1mm Long)			
			81	691740	Lock-Muffler Screw Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.			

★ Engine Gasket Set-Reference 358

● Carburetor Overhaul Kit-Reference 121

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
122	793456	Spacer-Carburetor Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.			0122, 0123, 0124, 0126, 0771.	238	793535	Cap-Valve
			202	793433	Link-Mechanical Governor Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	265	690798	Clamp-Casing Used on Type No(s). 0015, 0025, 0100, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0124, 0126.
125	793463	Carburetor (Primer System) Used on Type No(s). 0100.			----- Note ----- 793444 Link- Mechanical Governor Used on Type No(s). 0100.	267	691044	Screw (Casing Clamp) Used on Type No(s). 0015, 0025, 0100, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0124, 0126.
125A	793493	Carburetor (Ready Start System) Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	209	793427	Spring-Governor (Yellow) Used on Type No(s). 0015, 0025, 0100. ----- Note ----- 793430 Spring- Governor (White) Used on Type No(s). 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0122, 0123, 0124, 0126, 0771.	276	793627	Washer-Sealing
					793604 Spring- Governor (Purple) Used on Type No(s). 0121.	291	793498	Thermostat Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.
133	698539	Float-Carburetor Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	216	793494	Link-Choke Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0125, 0126, 0771.	300	793468	Muffler Used on Type No(s). 0100.
137	698538	Gasket-Float Bowl Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.			793679 Muffler Used on Type No(s). 0112, 0115, 0116, 0118, 0120.	300A	793496	Muffler Used on Type No(s). 0015, 0025, 0110, 0111, 0119, 0121, 0122, 0123, 0124, 0126, 0771.
163	691894	Gasket-Air Cleaner			793487 Bracket-Control Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	300B	793679	Muffler Used on Type No(s). 0112, 0115, 0116, 0118, 0120.
177	691031	Seal-O Ring (Dipstick) Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	222	793487	Bracket-Control Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	304	793486	Housing-Blower Used on Type No(s). 0015, 0025 0100, 0110, 0111, 0112, 0115, 0118, 0119, 0121, 0122, 0123, 0124,0126, 0771. ----- Note ----- 794105 Housing- Blower (Electric Start) Used on Type No(s). 0116, 0120.
187	791766	Line-Fuel (Cut to Required Length) Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121,	227	793516	Lever-Governor Control	309	794102	Motor-Starter Used on Type No(s). 0116, 0120.
			236	691826	Link-Lockout Used on Type No(s). 0015, 0025.			

★ Engine Gasket Set-Reference 358

● Carburetor Overhaul Kit-Reference 121

100600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
332	690662	Nut (Flywheel) (SAE) (.625-18 I.D.)	523	793475	Dipstick Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	613	793469	Screw (Muffler) Used on Type No(s). 0100.
332A	792723	Nut (Flywheel) (Metric) (M16x1.5mm I.D.)	524	793476	Seal-Dipstick Tube Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	----- Note ----- 793495 Screw (Muffler) Used on Type No(s). 0015, 0025, 0110, 0111, 0119, 0121, 0122, 0123, 0124, 0126, 0771.		
333	793449	Armature-Magneto	525	793477	Tube-Dipstick Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	615	690340	Retainer-Governor Shaft
334	793454	Screw (Magneto Armature)	535	793676	Filter-Air Cleaner Foam Used on Type No(s). 0015, 0025, 0771.	616	793448	Crank-Governor
337	692051	Plug-Spark Used on Type No(s). 0015, 0100, 0121.	562	793514	Bolt (Governor Control Lever)	621	692310	Switch-Stop Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0771.
----- Note ----- 692720 Plug-Spark Used on Type No(s). 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0122, 0123, 0124, 0126, 0771.			578	398153	Wire Assembly Used on Type No(s). 0015, 0025.	623	793628	Seal-O Ring (Carburetor Spacer)
356	692390	Wire-Stop Used on Type No(s). 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	578A	794104	Wire Assembly Used on Type No(s). 0116, 0120.	635	66538S	Boot-Spark Plug
358	793623	Gasket Set-Engine	592	793481	Nut (Rewind Starter)	662	793478	Stud (Rewind Starter) (M5x32.9mm Long) Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.
363	19069	Puller-Flywheel	601	791850	Hose-Clamp Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	662A	793479	Stud (Rewind Starter) (M5x49.6mm Long) Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0162, 0771.
365	793458	Screw (Carburetor) (27.0mm)	608	793470	Starter-Rewind Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.			
371	794574	Gear-Cam						
383	19374S	Wrench-Spark Plug						
404	690272	Washer (Governor Crank)						
425	793460	Screw (Air Cleaner Cover) (36.2mm)						
445	792038	Filter-Air Cleaner Cartridge						
474	794103	Alternator Used on Type No(s). 0116 0120.						
505	793515	Nut (Governor Control Lever)						
513	692358	Clutch-Drive Used on Type No(s). 0116, 0120.						

★ Engine Gasket Set-Reference 358

● Carburetor Overhaul Kit-Reference 121

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
670	793485	Spacer-Fuel Tank Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	843	691884	Sleeve-Lever Used on Type No(s). 0015, 0025, 0100, 0121, 0122.	922	692135	Spring-Brake Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0119, 0120, 0121, 0122, 0123, 0124, 0771.
718	690959	Pin-Locating (Cylinder)	847	793474	Diptstick/Tube Assembly Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	923	793490	Brake Used on Type No(s). 0015, 0025 0100, 0110, 0111, 0112, 0115, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.
741	793446	Gear-Timing	851	493880S	Terminal-Spark Plug	923A	794107	Brake Used on Type No(s). 0116, 0120.
742	93941	Retainer-E Ring Used on Type No(s). 0116, 0120.	857	793533	Trim-Blower Housing Cover Used on Type No(s). 0111, 0112, 0115, 0116, 0119, 0120, 0123, 0124, 0126, 0771.	925	793678	Cover-Linkage Used on Type No(s). 0118.
745	793491	Screw (Brake) (M5x25.3mm Long) Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	868	793507	Seal-Valve	937	494146	Spline-Starter Used on Type No(s). 0116, 0120.
783	691918	Gear-Pinion Used on Type No(s). 0116, 0120.	875	793462	Base-Air Cleaner Used on Type No(s). 0100.	942	793673	Bracket-Brake Used on Type No(s). 0015, 0025.
783A	691269	Gear-Pinion Used on Type No(s). 0116, 0120.	875A	793492	Base-Air Cleaner Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0118, 0116, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	955	793465	Plug-Carburetor Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0771.
787	793513	Arm-Lever	883	793497	Gasket-Exhaust Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	957	692046	Cap-Fuel Tank (Black) Used on Type No(s). 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0122, 0123, 0124, 0126, 0771.
793	793511	Screw/Nut Set (Lever Arm)	910	794101	Stud (Alternator) Used on Type No(s). 0116, 0120.	957A	793606	Cap-Fuel Tank (Black/Grey) Used on Type No(s). 0015, 0025 0121.
832	793499	Guard-Muffler Used on Type No(s). 0110, 0111, 0119, 0122, 0123, 0124, 0126, 0771.	914	699480	Screw (Rocker Cover) (15.8mm)			
832A	793681	Guard-Muffler Used on Type No(s). 0112, 0115, 0116, 0118, 0120.	921	793531	Cover-Blower Housing Used on Type No(s). 0111, 0112, 0115, 0116, 0119, 0120, 0123, 0124, 0126, 0771.			
836	793500	Screw (Muffler Guard) (M5x12.3mm Long) Used on Type No(s). 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0122, 0123, 0124, 0126, 0771.						

★ Engine Gasket Set-Reference 358

● Carburetor Overhaul Kit-Reference 121

100600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
968	793428	Cover–Air Cleaner Used on Type No(s). 0015, 0025, 0100, 0121, 0122.	976	694395	Primer–Carburetor Used on Type No(s). 0100.	1059	793471	Kit–Screw/Washer (Fuel Tank)
968A	793432	Cover–Air Cleaner Used on Type No(s). 0110, 0118.	1009	794099	Screw (Starter Motor) (M6x26mm Long) Used on Type No(s). 0116, 0120.	1095	793624	Gasket Set–Valve
968B	793532	Cover–Air Cleaner Used on Type No(s). 0111, 0112, 0115, 0116, 0119, 0120, 0123, 0124, 0126, 0771.	1022	793437	Gasket–Rocker Cover	1119	794100	Screw (Alternator) (M5x29.8mm Long) Used on Type No(s). 0116, 0120.
969	690700	Screw (Blower Housing Cover)	1023	793436	Cover–Rocker	1208	699776	Screw (Brake Bracket) Used on Type No(s). 0015, 0025.
972	793472	Tank–Fuel Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0771.	1036		Label–Emissions (Available from A Briggs & Stratton Authorized Dealer)	1263	697124	Reed–Breather
975	793464	Bowl–Float Used on Type No(s). 0015, 0025, 0100, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0121, 0122, 0123, 0124, 0126, 0771.	1058	MS3370	Operator’s Manual Used on Type No(s). 0015, 0025, 0110, 0111, 0112, 0115, 0116, 0118, 0119, 0120, 0123, 0124, 0126. ----- Note ----- MS3374 Operator’s Manual Used on Type No(s). 0110, 0118. 276373 Operator’s Manual Used on Type No(s). 0118. MS3371 Operator’s Manual	1264	793453	Screw (Breather Reed) (M4x12.4mm Long)
						1319	794467	Label–Warning
						1375	793442	Cover–Breather/Reed
						1376	699851	Screw (Breather/Reed Cover) (M5x9.5mm Long)
						1395	793459	Screw (Air Cleaner Base to Carburetor) (34 15/16” Long)

★ Engine Gasket Set–Reference 358

● Carburetor Overhaul Kit–Reference 121