# HUFFY SPORTS A Huffy Company

**Customer Service Center** N53 W24700 South Corporate Circle Sussex, WI 53089 U.S.A.

WRITE IN YOUR MODEL NUMBER: \_\_\_\_\_

# **Universal Elevator Mount Owners Manual**

# SAFETY INSTRUCTIONS

FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS MAY **RESULT IN SERIOUS INJURY,** PROPERTY DAMAGE AND WILL VOID WARRANTY. Owner must ensure that all players know and follow these rules for safe operation of the unit.

To ensure safety, do not attempt to assemble this system without following the instructions carefully. Check entire box and inside all packing material for parts. Before beginning assembly, read the instructions and identify parts using the hardware identifier and parts list in this document. Proper and complete assembly, use and supervision are essential for proper operation and to reduce the risk of accident or injury. A high probability of serious injury exists if this system is not installed, maintained, and operated properly.

- This equipment is intended for home recreational use only and NOT excessive competitive play.
- Read and understand the warning label enclosed with hardware. It is the responsibility of the customer to mount this label. It should be affixed to the pole, wall, or door near playing area, at a height between 4-6 feet (1.2 -1.8 m) above ground level and in a location visible to all players.
- ٠ During assembly, if using a ladder use extreme caution. Two people are recommended for this operation.
- If technical assistance is required, contact Huffy Sports.
- · Adult supervision is recommended when adjusting height.

## **Required Tools and** Materials:

NOTE: Due to various mounting methods, additional tools and materials may be required.

- Two People
- Tape Measure
- Pencil
- Wrenches: (Two) 7/16", 1/2", 9/16". 3/4" or Large and Small Adjustable Wrenches
- Step Ladder 8 ft. (2.4 m)
- Drill & Bit (3/8")
- Carpenter Level

Most injuries are caused by misuse and/or not following instructions. Use caution when using this unit.

#### **IMPORTANT!** Have questions...don't go back to the store!

We appreciate your purchasing one of our many fine products. We are sure that you will be very satisfied with your selection. Although great care and effort have been taken, occasionally problems may occur. To ensure prompt and correct handling of any problems, or to answer any questions, please contact our Toll-Free Customer Service Number listed below. Service will be quicker if you have your Model Number (found on carton) and assembly instructions ready when calling. PLEASE WRITE YOUR MODEL NUMBER IN THE SPACE PROVIDED ABOVE.


Toll-Free Customer Service Number for U.S: 1-800-558-5234 and Canada Only: 1-800-284-8339 Internet Address: http://www.huffysports.com

# AWARNING

#### FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY AND/OR PROPERTY DAMAGE.


Owner must ensure that all players know and


- follow these rules for safe operation of the unit.
  See instruction manual for proper installation and maintenance.
- Use caution when performing dunk type activities on this unit.
- Do not hang from any part of unit, including backboard, support braces, rim or net.
  - $\cdot$  Keep pole top covered with cap at all times.
- Do not slide, climb, shake or play on pole.
- Keep organic material away from pole base. Grass, litter, etc. could cause corrosion and/or deterioration.
- Check pole system for signs of corrosion (rust, pitting, chipping) and repaint with exterior enamel paint. If rust has penetrated through steel anywhere, replace pole immediately.
- Check unit before each use for loose hardware, excessive wear and signs of corrosion and repair before using.
- Check unit before each use for stability.
- During play, use extreme caution to keep player's face away from the backboard, rim or net. Serious injury could occur if teeth/face come in contact with backboard, rim or net.
- When adjusting height, keep hands and fingers away from moving parts. Do not allow children to adjust unit.
- During play, do not wear jewelry (rings, watches, necklaces, etc.) Objects may entangle in net.



## IMPORTANT! WRITE DOWN MODEL NUMBER FROM BOX ON PAGE 1 OF THIS OWNERS MANUAL


#### **ROOF MOUNTING**







## (1.)


Secure struts (3) to upper holes on u-channel (2). **NOTE: Position flat side of strut on u-channel.** Tighten until snug.





2. Install angle brackets (6 and 7) to lower holes on u-channel (2) and position angle brackets horizontally on roof. Tighten until snug.













## FOR POLE MOUNTING ONLY

Assemble mounting brackets (24) to 3-1/2" (8.9 cm) pole as shown. Position bracket assembly to approx. 106" (2.7 m) above level playing surface. Tighten nuts (28) completely. **NOTE: Equal rotations of nuts on each side of u-bolt (25) are necessary.** 



106" (2.7 m) PLAYING SURFACE

NOTE: Two people required for this procedure, elevator assembly is heavy. Mount assembled elevator components to mounting bracket (24) as shown. (Refer to Steps 6 through 13 for elevator assembly.)



1.

2.

### FLAT SURFACE MOUNTING

