


CONNECT WITH RELIABILITY



Copyright

Copyright © 1998 - 2007, Quatech, Inc. All rights are reserved. The information contained in this document cannot be reproduced in any form without the written consent of Quatech, Inc. Any software programs that might accompany this document can be used only in accordance with any license agreement(s) between the purchaser and Quatech, Inc. Quatech Inc. reserves the right to change this documentation or the product to which it refers at any time and without notice.

Trademarks

QUATECH® is a registered trademark of Quatech, Inc. Other product and brand names listed in this manual may be trademarks of their respective owners.

Disclaimer

The information in this manual is believed to be accurate and reliable at the time of posting. Notwithstanding the foregoing, Quatech assumes no responsibility for any damage or loss resulting from the use of this manual, and expressly disclaims any liability or damages for loss of data, loss of use, and property damage of any kind, direct, incidental or consequential, in regard to or arising out of the performance or form of the materials presented herein or in any software program(s) that may accompany this document.

Changes or modifications to this device not explicitly approved by Quatech will void the user's authority to operate this device.

Feedback

Quatech, Inc. encourages and appreciates feedback concerning this document. Please send any written comments to the Technical Support department at the address listed on the cover page of this manual.

Table of contents

| Table of contents | i |
|---|----------|
| Figures | ii |
| Introduction | 1 |
| System requirements | ······ 1 |
| Installing the Parallel Port Adapter | 2 |
| Installing under Windows XP | |
| Uninstalling under Windows XP | |
| Installing under Windows Vista | |
| Uninstalling under Windows Vista | 11 |
| Making external connections | 12 |
| Using Device Manager | 13 |
| Accessing Device Manager | |
| Exploring Device Manager screens Windows XP / Vista | |
| Troubleshooting | 18 |
| Appendix A | 19 |
| Specifications | |
| Warranty information | 20 |

Figures

| Figure 1 - Windows XP Found new hardware prompt | 2 |
|--|----|
| Figure 2 - Windows XP Choose your installation options prompt | |
| Figure 3 - Windows XP "software has not passed Windows logo testing" prompt | 4 |
| Figure 4 - Windows XP "please wait" message | |
| Figure 5 - Windows XP Finished installing prompt | |
| Figure 6 - Device Manager | |
| Figure 7 - Windows Vista "Found new hardware" prompt | 7 |
| Figure 8 - "Windows needs your permission to use this program" prompt | |
| Figure 9 - Windows Vista "Insert the disc that came with your hardware" prompt | 8 |
| Figure 10 - Windows Vista "Windows can't verify the publisher of the driver software" prompt | 9 |
| Figure 11 - Windows Vista "Installing driver software" message | 10 |
| Figure 12 - Windows Vista "the software has been successfully installed" prompt | 10 |
| Figure 13 - Device Manager | 11 |
| Figure 14 - DB-25 female parallel port connector | 12 |
| Figure 15 - Windows XP Device Manager - Adapter properties, General tab | 14 |
| Figure 16 - Windows XP Device Manager - Adapter properties, Port Settings tab | 15 |
| Figure 17 - Windows XP Device Manager - Adapter properties, Driver tab | |
| Figure 18 - Windows XP Device manager - Adapter properties, Driver file details box | |
| | |

Page ii Rev 1.00 (July 2007)

Introduction

This User's Manual describes how to setup and install your Quatech Parallel Port Adapter.

The Quatech SPPXP-100 provides one parallel port to the host PC via the ExpressCard port.

The adapter is a Plug-and-Play device and requires no hardware configuration.

System requirements

Quatech Parallel Port Adapters are supported under the Windows XP (and later) operating systems. All device drivers are available for download from the Quatech World Wide Web site at http://www.quatech.com/.

Installing the Parallel Port Adapter

Caution! Be sure to allow the installation process to finish without interruption. This section explains how to install the Parallel Port Adapter under different operating systems. Please locate and follow the procedure for your computer's operating system.

The Parallel Port Adapter uses the Windows system-supplied parallel drivers that enables the port to appear to Windows as a standard LPT port.

Installing under Windows XP

Follow these steps to install the adapter under Windows XP.

| Step | Procedure | Description |
|----------|--|--|
| □ Step 1 | Turn on the power to your computer system. | This is the system in which the device is to be installed. |
| □ Step 2 | Plug the ExpressCard into an available ExpressCard slot on the computer. | Windows tells you that it has found new hardware and launches the Found New Hardware Wizard. |

Figure 1 - Windows XP Found new hardware prompt

Figure 1 illustrates the Windows XP Found new hardware prompt. The Found New Hardware Wizard launches automatically when you first plug in the Parallel Port Adapter.



| Step | Procedure | Description |
|----------|--|--|
| □ Step 3 | When the "welcome to the found new hardware wizard" appears, select the "No, not this time" option | Please do NOT allow Windows Update to search for the software on the internet. |
| □ Step 4 | Click the Next button | Windows will continue to the next step. |

Page 2 Rev 1.00 (July 2007)

This wizard helps you install software for:

Quatech SPPXP-100 ExpressCard IEEE-1284 Parallel Adapter

If your hardware came with an installation CD or floppy disk, insert it now.

What do you want the wizard to do?

Install the software automatically (Recommended)

Click Next to continue.

Figure 2 - Windows XP Choose your installation options prompt

| | Procedure | Description |
|----------|--|--|
| □ Step 5 | Insert the Quatech installation CD into your CD-ROM drive. | This is the CD that shipped with the product. |
| □ Step 6 | Select the "install automatically (Recommended)" option. | $The\ installation\ options\ prompt\\ displays.$ |
| □ Step 7 | Click the Next button. | Windows searches for drivers for the adapter. |

Figure 3 - Windows XP "software has not passed Windows logo testing" prompt

Figure 3 illustrates the "software has not passed Windows logo testing" prompt. This prompt will only appear in the case of a new unsigned driver.



| Ste | p | Procedure | Description |
|-----|--------|---|--|
| | Step 8 | In the case of a new unsigned driver, the "software has not passed Windows logo testing" prompt will appear. Please click the [Continue Anyway] button to continue with the installation. | Windows displays a warning prompt if the software drivers are not signed with the Windows logo. New drivers have been tested at our lab facilities, but may not yet have received the official logo from Microsoft. |
| | Step 9 | The Wizard locates and starts to install the necessary software. | The "wait while the Wizard installs the software" prompt displays (fig.4), followed by the "Finished installing" prompt (fig.5). |

Page 4 Rev 1.00 (July 2007)

Figure 4 - Windows XP "please wait" message




Figure 5 - Windows XP Finished installing prompt




| Step | Procedure | Description |
|-----------|--------------------------------------|---|
| □ Step 10 | Press the Finish button to continue. | $The \ Express Card \ Adapter \ installation \ is \\ complete.$ |

Uninstalling under Windows XP

Follow these steps in the event that you need to uninstall or reinstall the Parallel Port software.

- 1. From the Control Panel, select System.
- 2. Press the Hardware tab.
- Click on Device Manager.

Figure 6 - Device Manager



- 4. Scroll down to PORTS and expand.
- Highlight your Quatech Parallel Port Adapter; for example, Quatech SPPXP-100 ExpressCard IEEE-1284 Parallel Adapter (LPT3)
- 6. Select the Action menu option.
- 7. Select Uninstall from the drop down menu.
- 8. Click OK at the Confirmation screen. Note that this also removes the parallel port associated with your Parallel Port Adapter.

Page 6 Rev 1.00 (July 2007)

Installing under Windows Vista

Follow these steps to install the adapter under Windows Vista.


| Step | Procedure | Description |
|----------|--|--|
| □ Step 1 | Turn on the power to your computer system. | This is the system in which the device is to be installed. |
| □ Step 2 | Plug the ExpressCard into an available ExpressCard slot on the computer. | Windows tells you that it has found new hardware and launches the Found New Hardware Wizard. |

Figure 7 - Windows Vista "Found new hardware" prompt

Figure 7 illustrates the Windows Vista Found new hardware prompt. The Found New Hardware Wizard launches automatically when you first plug in the Parallel Port Adapter.




Figure 8 - "Windows needs your permission to use this program" prompt



| Step | Procedure | Description |
|----------|--|---|
| □ Step 3 | When the "welcome to the found new hardware wizard" appears, select the "Locate and install driver software (recommended)" option | Windows will pop-up the next prompt. |
| □ Step 4 | When the "Windows needs your permission to use this program" prompt appears, select [allow] to continue with the install ation. | Windows will continue to the next step. |

Figure 9 - Windows Vista "Insert the disc that came with your hardware" prompt



| | Procedure | Description |
|----------|--|---|
| □ Step 5 | Insert the Quatech installation CD into your CD-ROM drive. | This is the CD that shipped with the product. |
| □ Step 6 | Click the Next button | Windows searches for drivers for the adapter. |

Page 8 Rev 1.00 (July 2007)

Figure 10 - Windows Vista "Windows can't verify the publisher of the driver software" prompt

Figure 10 illustrates the "Windows can't verify the publisher of the driver software" prompt.

This prompt will only appear in the case of a new unsigned driver.



| Step | | Procedure | Description |
|------|--------|--|--|
| | Step 7 | In the case of a new unsigned driver, the "Windows can't verify the publisher of the driver software" prompt will appear. Please click on [Install this driver software anyway] to continue with the installation. | Windows displays a warning prompt if the software drivers are not signed with the Windows logo. New drivers have been tested at our lab facilities, but may not yet have received the official logo from Microsoft. |
| | Step 8 | The Wizard locates and starts to install the necessary software. | The "wait while the Wizard installs the software" prompt displays (fig.11), followed by the "Finished installing" prompt (fig.12). |

Figure 11 - Windows Vista "Installing driver software" message





Figure 12 - Windows Vista "the software has been successfully installed" prompt



| Step | Procedure | Description |
|----------|-------------------------------------|---|
| □ Step 9 | Press the Close button to continue. | The ExpressCard Adapter installation is complete. |


Page 10 Rev 1.00 (July 2007)

Uninstalling under Windows Vista

Follow these steps in the event that you need to uninstall or reinstall the Parallel Port software.

- 1. From the Control Panel, select System.
- 2. Select "Classic view".
- 3. Click on Device Manager.
- 4. When the security prompt appears, click [allow] to continue.

Figure 13 - Device Manager



- 5. Scroll down to PORTS and expand.
- 6. Highlight your Quatech Parallel Port Adapter; for example, SPPXP-100 ExpressCard IEEE-1284 Parallel Adapter (LPT3).
- 7. Select the Action menu option.
- 8. Select Uninstall from the drop down menu.
- 9. Click OK at the Confirmation screen. Also click the check-box to remove the driver software. Note that this also removes the parallel port associated with your Parallel Port Adapter.

Making external connections

The following figures and tables show the parallel port pinouts.

Figure 14 - DB-25 female parallel port connector




Table 1 - Parallel Port Pin Assignments

| Pin # | Source | Compatible | Nibble | Byte | ECP | EPP |
|-------|---|-------------------------|-------------------------------|--------------------|-----------------|----------------|
| 1 | Н | nStrobe | HostClk | HostClk | HostClk | nWrite |
| 2 | Bi-Di* | | Data 1 (Leas | st Significant Bit |) | AD1 |
| 3 | Bi-Di* | | I | Data 2 | | AD2 |
| 4 | Bi-Di* | | I | Data 3 | | AD3 |
| 5 | Bi-Di* | | I | Oata 4 | | AD4 |
| 6 | Bi-Di* | | I | Oata 5 | | AD5 |
| 7 | Bi-Di* | | I | Oata 6 | | AD6 |
| 8 | Bi-Di* | | Data 7 | | | AD7 |
| 9 | Bi-Di* | | Data 8 (Most Significant Bit) | | | AD8 |
| 10 | P | nAck | PtrClk | PtrClk | PeriphClk | Intr |
| 11 | P | Busy | PtrBusy | PtrBusy | PeriphAck | nWait |
| 12 | P | PError | AckDataReq | AckDataReq | nAckReverse | User defined 1 |
| 13 | P | Select | Xflag | Xflag | Xflag | User defined 3 |
| 14 | Н | nAutoFd | HostBusy | HostBusy | HostAck | nDStrb |
| 15 | P | nFault | nDataAvail | nDataAvail | nPeriphRequest | User defined 2 |
| 16 | Н | nInit | nInit | nInit | nReverseRequest | nInit |
| 17 | Н | nSelectIn | | IEEE 1284 Act | ive | nAStrb |
| 18 | | Signal Ground (nStrobe) | | | | |
| 19 | Signal Ground (Data 1 and Data 2) | | | | | |
| 20 | Signal Ground (Data 3 and Data 4) | | | | | |
| 21 | Signal Ground (Data 5 and Data 6) | | | | | |
| 22 | Signal Ground (Data 7 and Data 8) | | | | | |
| 23 | Signal Ground (Busy and nFault) | | | | | |
| 24 | Signal Ground (PError, Select, and nAck) | | | | | |
| 25 | Signal Ground (nAutoFd, nSelectIn, and nInit) | | | | | |

Page 12 Rev 1.00 (July 2007)

Using Device Manager

This section explains how to use Device Manager to view the properties of the parallel ports enumerated by the Parallel Port Adapter.

Accessing Device Manager

| Step | Procedure | Description | |
|----------|--|--|--|
| □ Step 1 | Select Start – Control Panel. | | |
| □ Step 2 | Double click the System icon. | The System Properties dialog box opens. | |
| □ Step 3 | Click the Hardware tab, and then press the Device Manager button. | Device Manager lists all the hardware devices that are registered inside the Windows registry. | |

Exploring Device Manager screens

Windows XP / Vista

Device Manager provides one property dialog that applies to the Parallel Port Adapter.

> Ports (COM & LPT) device group property box


Use the Ports (COM & LPT) device group property box to view and set the port settings and to view device usage and driver information for the parallel ports.

Vista Users, please note that aside from some aesthetic changes, the on-screen displays are virtually identical to the ones shown from XP

| Step | Procedure | Description |
|----------|---|---|
| □ Step 1 | With Device Manager open, expand the PORTS group. | Your Parallel Port Adapter should appear in the list – for example, SPPXP- 100 ExpressCard IEEE-1284 Parallel Adapter (LPT3) (see fig.6) |
| □ Step 2 | Double click the Parallel Port Adapter. | The Properties dialog box opens and displays the General tab. |

Figure 15 - Windows XP Device Manager - Adapter properties, General tab

Figure 15 illustrates the Adapter Properties, General Tab which tells you whether the Adapter is working properly




| Step | Procedure | Description |
|----------|---|--|
| □ Step 3 | Click the ExpressCard Parallel Adapter Port Settings tab to view the port setting properties. | The Port Settings dialog box displays. |

Page 14 Rev 1.00 (July 2007)

Figure 16 - Windows XP Device Manager - Adapter properties, Port Settings tab


Figure 16 illustrates the Adapter Properties, Port Settings Tab.



| Step | Procedure | Description |
|----------|---|---|
| □ Step 4 | The ExpressCard Parallel Adapter Port Settings Tab allows you to | See the Setting advanced options section for details. |
| | Select interrupt options | |
| | Select "plug & play" options | |
| | > Set the port number. | |
| □ Step 5 | Click Cancel or OK to close the property box. | |

Figure 17 - Windows XP Device Manager - Adapter properties, Driver tab

Figure 17 illustrates the Adapter Properties, Driver Tab, which lets you view the driver details and update, roll back, or uninstall the driver.




| Step | Procedure | Description | |
|----------|--|--|--|
| □ Step 6 | Click the Driver tab to view the driver information and update the driver. | The ExpressCard Parallel Port Driver properties dialog box displays. | |
| □ Step 7 | You have several options: View detailed driver information Update the device drivers Uninstall your Parallel Port Adapter. Return to the previously installed driver. Save your changes and exit. Abandon your changes and return to the Device Manager. | See below. | |
| □ Step 8 | Click the Driver Details button to view detailed driver information. | The Driver File Details dialog box opens. See the following figure. | |

Page 16 Rev 1.00 (July 2007)

Figure 18 - Windows XP Device manager - Adapter properties, Driver file details box

Figure 18 illustrates the Driver Details dialog box, which tells you the name and location of the driver files, the provider, file version, copyright date, and the digital signature status of the driver.



| Step | Procedure | Description | |
|-----------|---|---|--|
| □ Step 9 | The Driver File Details dialog box displays the following information | | |
| | Provider | Microsoft is the provider of the driver. | |
| | File version | This is the version number of the installed software. | |
| | Copyright | Copyright date and holder | |
| | Digital Signer (Windows XP only) | Indicates whether Microsoft has | |
| | Click OK to return to the Driver tab. | approved this version. | |
| □ Step 10 | Click Cancel or OK to close the dialog. | | |

Troubleshooting

Note: Any unauthorized repairs or modifications will void the adapter's warranty.

This section lists some common problems and their causes. If the information below does not provide a solution, contact Quatech technical support.

| Problem | Cause | Solution |
|---|-------------------------------------|---|
| The Parallel Port Adapter cannot communicate with other equipment. | The card is not seated properly. | Check the card to make sure that it is firmly seated in the card slot. |
| | The device driver is not installed. | 1. Double check the Device Manager per the instructions in Using Device Manager to ensure that drivers are installed correctly and that all devices are working properly. |
| | | Try uninstalling the ExpressCard Adapter from the Device Manager window and then repeat the hardware installation instructions. |
| | The ExpressCard port is faulty. | If possible, connect a known good ExpressCard device to the PC and see if it operates properly. |

Page 18 Rev 1.00 (July 2007)

Appendix A

Specifications

| Bus interface | PCI Express, revision 1.1 | |
|--------------------|---|--|
| Ports | SPPXP-100: 1 | |
| PPI | Custom Parallel Peripheral Interface Controller with 2048 byte ECP FIFO. | |
| Transceivers: | IEEE-1284 Output | |
| | Voltage Swing: $0.4 - 2.4V$ min, $0.5V$ typical | |
| | IEEE-1284 Input | |
| | Voltage Range: -0.5V min, +5.5V max | |
| | Input Threshold Low: 0.8V max | |
| | Input Threshold High: 2.0V min | |
| Connectors: | ctors: DB-25 Female | |
| Dimensions | See drawing | |
| Power Requirements | +3.3v = <1000mA | |
| | +3.3v aux = 0 mA | |
| | +1.5v = 0 mA | |
| Temperature: | Operating: 0 to 70 C | |
| | Storage: -50 to 80 C | |
| Humidity | 10 to 90% | |
| OS Support | Windows XP, Windows Vista | |

Appendix B

Warranty information

Quatech, Inc. warrants the SPPXP-100 to be free of defects for five (5) years from the date of purchase. Quatech, Inc. will repair or replace any board that fails to perform under normal operating conditions and in accordance with the procedures outlined in this document during the warranty period. Any damage that results from improper installation, operation, or general misuse voids all warranty rights. No representation is made regarding the suitability of this product for any particular purpose.

| Please complete the following info | ormation and retain for your records. |
|------------------------------------|---------------------------------------|
| DATE OF PURCHASE: | |
| MODEL NUMBER: | SPPXP-100 |
| PRODUCT DESCRIPTION: | Parallel Port Adapter |
| SERIAL NUMBER: | |

All products returned to Quatech for either warranty or non-warranty repair MUST be assigned a Returned Material Authorization (RMA) number prior to shipment. This RMA number must be clearly marked on the exterior of the product's return packaging and in any correspondence to ensure proper routing and prompt attention. To obtain an RMA number, contact Quatech Technical Support Department at 1-800-553-1170 or (330) 655-9000. In order to prevent damage to returned merchandise during shipment, please package electronic components in anti-static/shock proof materials.

For **warranty** repair/returns, please have the following information available when contacting the Technical Support department:

- 1. Model number and serial number of the product under warranty
- 2. Repair instructions and/or specific description of the problem

For **non-warranty** repairs or upgrades, contact the Technical Support department for current repair charges and please have the following information available:

- 1. Purchase order number to cover the cost of the service
- 2. Model number and serial number of the product
- 3. Repair or upgrade instructions relative to the product

Page 20 Rev 1.00 (July 2007)