
TS86A Powerpile® Easy-To-See™ Thermostat

HOMEOWNER'S GUIDE

FEATURES OF YOUR NEW THERMOSTAT

- 1. Enlarged, raised numbers indicate temperature range for easy recognition by touch or sight. The large 5, 6, 7 and 8 indicate 50°F, 60°F, 70°F and 80°F, respectively.
- Raised temperature setting knob lets you choose settings from 42°F to 88°F.
- 3. Temperature setting scale is separate from thermometer scale on face of thermostat.
- 4. Thermometer shows room temperature.



See Reverse Side



TEMPERATURE SELECTION

To select the temperature control point, turn the transparent dial until the desired point on the temperature setting scale (upper scale) is in line with the pointer on the dial. A *click* is heard and an indent felt every two degrees as the setpoint is adjusted. A deeper indent is felt at each ten degree mark for easy energy saving setting at night.

The enlarged cover ring includes raised temperature graduations every two degrees Fahrenheit. The enlarged raised 5, 6, 7 and 8 provide recognition by touch and sight for the 50°F, 60°F, 70°F and 80°F points.

Honeywell