## 30" Freestanding Electric Range


## PRODUCT MODEL NUMBERS

ROPER


## OVERALL DIMENSIONS



**Electrical:** This range can be direct wired to a four-wire or three-wire, 8 gauge copper or 6 gauge aluminum wire wiring system or a range power supply cord can be used. A four-wire or three-wire, single-phase, 120/240-volt, 60 Hz, AC-only, electrical supply is required on a 40 amp circuit, (or, if specified on the model/serial rating plate, a four-wire or three-wire, single-phase 120/208-volt, 60 Hz, AC-only electrical supply is available, a 40 amp circuit), fused on both sides of the line. A time-delay fuse or circuit breaker is recommended. The model/serial rating plate is located on the oven frame behind the storage drawer panel.



## CABINET OPENING DIMENSIONS



Because Whirlpool Corporation policy includes a continuous commitment to improve our products, we reserve the right to change materials and specifications without notice. Dimensions are for planning purposes only. For complete details, see Installation Instructions packed with product. Specifications subject to change without notice.