



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1		Upper Cover	
1a	27257	Upper Cover (Model AG)	1
2		Cord Set	
2a	21839	BS Style Cord Set (Models AG & BG)	1
2b	27158	VDE Style Cord Set (Model AG & BG)	1
2c	21824	SAA Style Cord Set (Models AG & BG)	1
3	65828	Screw	2
4	22034	Speed Control	1
5	-	-	
6	21936	Brush Repair Kit	1
7	21766	Brush Housing Assembly (incl. 8, 9, 31)	1
8	21765	Brush Holder	2
9	21021	Set Screw	2
10		Lower Housing	
10a	21331	Lower Housing (Model AG/BG 220V)	1
10b	21333	Lower Housing (Model AG/BG 240V-U.K.)	1
10c	21335	Lower Housing (Model AG/BG 240V-Aus)	1
11	25018	Hanger Bail	1
12	21050	Rear Housing Screw	2
13	21048	Front Housing Screw	2
14	21067	Bearing Mounting Ring	1
15	27352	Field Assembly	1
16	21977	Armature Assembly with Plastic Cam	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
17	27854	Plastic Cam & Bearing Assembly	1
18	21068	Bearing Mounting Ring	1
19	21014	Blade Retaining Spring	1
20		Hinge Assembly	
20a	S27164	Hinge Assembly (Model AG)	1
20b	S21743	Hinge Assembly (Mdl BG & Oster 76 & 89 Blade Compatibility)	1
21	27861	Blade Hinge Screw	1
22	64139	Blade Screw	1
23	64003	Blade Bracket	1
24	64197	Tension Spring	1
25	64027	Blade Guide	1
26	27181	Front Motor Frame Assembly	1
27	S20651	Blade Drive Assembly	1
28	15766	Blade Drive Screw	2
29	21018	Switch Actuating Arm	1
30	27198	Motor Frame Retaining Clip	2
31	21130	Brush End Housing	1

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.