



PHILIPS





Use the headphones

Use of the headphones draws battery from your iPod, and iPod playtime is affected.

To save your iPod power, please switch off your headphones after use.

- 1 To have a better noise cancelling effect, select the most suitable caps for your ears.
- Connect the iPod connector to your iPod (Fig. 1).
- 3 Adjust the slide switch to NC ON (Fig. 2) to enable noise canceling function.
 - → LED light turns blue.
 - To disable noise canceling function, adjust the slide switch to NC OFF.
 - → LED light turns green.
- 4 Use the control panel to control your iPod (Fig 3).

44 / >>	Skip to the previous/next track Hold to scroll fast backward/forward
+/ -	Adjust volume level
►II	Play/Pause iPod Hold to switch off the iPod

- 5 Clip the headphones on your bag (Fig. 4) or shirt (Fig. 5).
- 6 After use, adjust the slide switch to OFF to switch off the headphones.
 - → LED light turns off.



