



SPEAKER STAND

扬声器支架 揚聲器支架



INSTRUCTIONS

使用说明书 使用說明書

Warnings, Cautions and Others

Warning

Observe the following carefully before installation; otherwise, the speaker may fall over, causing damage or injury.

- Do not install the speaker stand on an uneven surface or in a place subject to vibration.
- Do not lean against the speaker stand. Especially pay attention to children not to do so.
- Fasten all the screws firmly when assembling the speaker stand, and check its tightness afterwards regularly.
- Do not install any overweight equipment (over 10 $\rm kg)$ on the speaker stand.

Precautions

For safety use

- Do not climb or hang on to the speaker stand.
- Attach the speaker firmly to the speaker stand.

· For installation


- While installing the speaker on the stand, do not drop it from the stand. Pay attention not to damage the speaker cabinet.
- To obtain the best bass sound quality, install the speaker stand on the flat floor.


For daily use


- Wipe with a dry, soft cloth if the speaker stand should become dirty. If very dirty, wipe with a cloth applied a small amount of water or neutral detergent, then wipe with a dry cloth.
- Do not use chemicals such as benzine and thinner for cleaning the speaker stand; otherwise, the speaker stand may deteriorate or its paint may come off.


■ Checking the supplied parts


Check to be sure you have the following supplied parts. The quantity of piece supplied is for one pair of speaker stands.




















If any item is missing, contact your dealer immediately.

Assembly


Before assembling-

- · Prepare a Phillips screwdriver.
- Place a large, thick cloth on the floor where you assemble the speaker stand to protect the floor and the speaker stand.

Assembling the speaker stand


 Tighten the screws firmly so that no space is left between the legs and plates.

1 Fix the top plate.



* The side without spacer should face outside.

2 Fix the bottom plate and leg holders.



3 Finally tighten screws $ext{(A)}$ and $ext{(B)}$ fully.

 Tighten them firmly and fully so that no space is left between the legs and plates.

Installing Speaker


■ Attach the speaker on the stand

1 Locate the speaker properly by aligning both screw holes of the speaker and the speaker stand.


- Do not install the speaker stand on an uneven surface or in a place subject to vibration.
- \bullet Do not install any overweight equipment (over 10 $\mathrm{kg})$ on the speaker stand.

2 Fix the speaker with the supplied screws © (M5 x 28 mm).

 Do not overtighten the screws, but firmly enough to prevent the speakers from being shaky.



Specifications



Design and specifications subject to change without notice.

JVC