

# Roxygen Pack

Designed for use with Rock Band™ Guitar.

Model: BH4001

Thank you for purchasing this Rock Band™ Roxygen Pack. We hope you enjoy it. For your personal safety and for the safety of others, please carefully read this instruction manual as well as the instruction manuals that came with your game consoles and games.

## Precautions


- Make sure to read the Instruction Manual of the Rock Band™ Roxygen Pack before using the product.
- Keep all liquids away from this product. Getting this product wet will void your warranty
- Do not spill the water on the product. This would void your warranty.
- Do not insert objects of any kind into the product as this may cause damage or a fire hazard and void your warranty.
- Make sure small children are supervised while playing.
- Keep the Rock Band™ Roxygen Pack out of environments of extreme heat and extreme cold.
- Please make sure to insert the battery properly into the guitar or other device. If you insert the battery backwards this would void your warranty.
- If you have any technical or functional problems with the Rock Band™ Roxygen Pack, please contact Customer Service and do not try to modify the product or fix the problem yourself as this would void your warranty.
- When the Rock Band™ Roxygen Pack is not in use, make sure to store it properly for both safety and preservation of the product.

## Contents


- 1 recharge station
- 1 battery pack
- 1 USB charging cable

## Quick Setup Guide


### Charge the battery pack

① 

- Insert the battery pack into the recharge station. Make sure the positive side matches with positive and the negative side matches with negative.


② 

- Connect the recharge station with any USB port using the USB charging cable.


③ 

- The red Charging Indicator lights up and charging begins. When charging has completed, the Charging Indicator turns off and the blue Fully Charged Indicator lights up.

### Use the battery pack

① 

- Remove the battery cover on the bottom of the guitar and insert the battery pack. Make sure the positive side matches with positive and the negative side matches with negative.

② 

- Use the screw to fix the battery pack in the battery compartment.

## WARRANTY AND TECHNICAL SUPPORT

Every Blockhead branded product comes with a 90 day warranty (U.S. Only). Blockhead will replace, repair or refund any defective products or components at no charge to you within 90 days of the purchase date. This warranty does not apply if the Blockhead branded product has been damaged by misuse, neglect, or reasons unrelated to defective materials or assembly. Blockhead is not responsible or liable for loss of data or loss of equipment use. You must retain a copy of your original receipt for warranty support.

For support on Blockhead products, contact us by visiting [www.blockheadgaming.com](http://www.blockheadgaming.com) or call us at 727-431-0650.

For general questions, comments, information or grammar tips, email us at [info@blockheadgaming.com](mailto:info@blockheadgaming.com).