

## VM-99 VidiMax

Brush and cleaning-pad system for specialized glass surfaces.



The VidiMax is a brush and cleaning-pad system for glass computer screens and any specialized glass surface. It's super—soft brush wipes dust particles from screens, and the remarkable non-liquid cleaning compound removes messy fingerprints quickly and easily. Safe for all TV screens, LCD screens, computer monitors and laptop screens, scanners, copiers, and other high-quality glass screens. This unique cleaning compound will not spill or dry-out and is environmentally friendly and non-toxic.

## Directions:

- -Pull handle back and up, this releases VidiMax brush from its base. Wipe dust particles from screen surface.
- -Place VidiMax brush back into base. Push button and slide back VidiMax cleaning-pad.
- -Wipe screen with smooth circular motions of the soft chamois cleaningpad. If any smudges persist, breathe gently on the surface to be cleaned and repeat process.
- -Slide VidiMax cleaning-pad back onto VidiMax brush and base. This replenishes the unique cleaning compound.

## Note:

Do not use on wet surfaces. Follow all directions carefully for safe use.