

Sunbeam salon technique **IONIC**1800w

Instruction Booklet HD7850P

Please read these instructions carefully and retain for future reference.



Contents

Sunbeam's Safety Precautions	1
Features of your lonic 1800w Hairdryer	2
Using your Ionic 1800w Hairdryer	4
Care and Cleaning	5

تأكد من تفهم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich daß die obenstehenden Sicherheitsmaßnahmen Verstanden werden

Βεβαιώνετε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

كارى بكنيد كه احتياطهاى بالاحتماً درك بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR YOUR SUNBEAM HAIRDRYER

- This hairdryer must not come into contact with water or any other liquid.
- Always switch off your hairdryer at the power outlet and remove the plug when not in use.
- Do not store your hairdryer near tubs, basins, baths or other vessels containing water or any other liquid.
- When the hairdryer is used in the bathroom, unplug it after use as the proximity of water presents a hazard even when the unit is switched off.


Sunbeam are very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:


- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible adult to ensure that they can use the appliance safely.

- Young children should be supervised to ensure that they do not play with the appliance.
- Never leave an appliance unattended while in use.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven. Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

Features of your Ionic 1800W Hairdryer





Using your Ionic 1800W Hairdryer

The controls

- Your dryer has two heat and two speed settings. This combination allows for greater versatility and control when drying and styling your hair.
- Setting I produces a lower temperature and gentle airflow for greater control when styling.
- Setting II produces a higher temperature and stronger airflow and is ideal for fast drying.
- The cool shot setting provides a burst of cool air to set the style in place once styled.

Ionic Technology

- The built in ionic generator automatically produces a constant stream of negative ions whenever the hairdryer is in use.
- The ion indicator light will light up whilst your dryer is in use.

Using your dryer

- After shampooing and conditioning your hair, squeeze excess moisture from the hair using a dry towel.
- Comb hair free of tangles using a wide tooth comb.
- Plug your dryer into a power outlet and turn on the power.
- Select the desired setting and using your fingers, dry hair from roots to ends.
- Use the concentrator nozzle on specific areas of the hair for spot drying or styling.
- Use the diffuser on naturally curly, wavy or permed hair. The vented fingers take warm air directly to the root of the hair to add extra volume.
- The concentrator nozzle and diffuser simply click into place. To remove pull them off.
- Always hold the dryer at least 30 cm away from the hair when drying.

Warning – The diffuser may become hot after extended use. Allow to cool before removing or storing.

Care and Cleaning

- Turn your hairdryer off after use. Always turn the power off and remove the plug before cleaning.
- Do not immerse the hairdryer in water or any other liquid.
- To clean the exterior, simply wipe over with a dampened cloth and wipe dry.
- Pull off the removable cover and remove any hair and lint from the grille.

- Click back into position before using again.
- Clean the inside of the cover regularly to maximize the life of the dryer.
- Do not wind the cord around the dryer as this may strain and damage the wiring.

Notes



2 Year Replacement Guarantee

We are so confident of the quality of our product, should this appliance develop any malfunction within 2 years of purchase (3 Months commercial use) due to faulty materials or manufacture, we will replace it for you absolutely free.

Should you experience any difficulties with your appliance, please phone our free call customer service line for advice on 1800 025 059 in Australia, or 0800 786 232 in New Zealand.

Alternatively, simply return the faulty appliance to your place of purchase, along with your purchase receipt.

Your Sunbeam 2 Year Replacement Guarantee naturally does not cover misuse or negligent handling, and excludes breakables such as glass or ceramic items, and normal wear and tear.

Similarly, your 2 Year Replacement Guarantee does not cover damage to household surfaces as a result of water or other substances leaking from your appliance, nor does it cover freight costs.

In Australia, this guarantee is additional to the conditions and guarantees which are mandatory as implied under the Trade Practices Act 1974 and State and Territory legislation.

Sunbeam Service Centres

Sunbeam has established a network of authorised service centres throughout Australia and New Zealand to provide quick, convenient service for our customers.

Should your appliance require repair or service, either during or after the guarantee period, contact your nearest service centre.

For a complete list of Sunbeam's authorised service centres:

Australia

www.sunbeam.com.au/service centres 1800 025 059

New Zealand

www.sunbeam.co.nz/service centres 0800 786 232



Consumer Hotline

In Australia Visit www.sunbeam.com.au Or Call 1800 025 059

In New Zealand Visit www.sunbeam.co.nz Or call 0800 786 232



Sunbeam is a registered Trademark of Sunbeam.

'Salon Technique' is a trademark of Sunbeam Corporation. Made in China. Due to minor changes in design or otherwise,

the product may differ from the one shown in this leaflet.

© Copyright. Sunbeam Corporation Limited 2006. ABN 45 000 006 771

Sunbeam Corporation is a division of GUD Holdings Ltd.