Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.



ITEM 94668



Visit our website at: http://www.harborfreight.com Email our technical support at: productsupport@harborfreight.com



REV 14h

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright[©] 2006 by Harbor Freight Tools[®]. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

AWARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Specifications

Overall Length	17-1/2"
LED Lights	30
Charging Indicator Light	1
Light Wattage	40
Battery	7.2V, 600mA/H rechargeable NiMH, lasts up to 2 hours
Adapter	9V AC/DC
Includes	Cigarette Lighter Charger, 2 additional hanging hooks

Important Safety Information

WARNING: When using product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

- Keep work area clean and well lighted. Cluttered areas invite injuries.
- Store idle equipment. When not in use, the Worklight must be stored in a dry location. Always lock up products and keep out of reach of children.
- Use the right product for the job. There
 are certain applications for which the
 Worklight was designed. Do not modify the
 Worklight and do not use the Worklight for
 a purpose for which it was not intended.
- 4. Check for damaged parts. Before using any product, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for any broken or damaged parts and any other conditions that may affect its operation. Replace or repair damaged or worn parts immediately.
- Replacement parts and accessories.
 When servicing, use only identical replacement parts. Use of any other parts will void the warranty.

- Do not operate product if under the influence of alcohol or drugs. Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate the product.
- Do not expose the Worklight to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- Do not abuse the Power Cord. Never use the Power Cord to carry the Worklight or to pull the Plug from an outlet. Keep the Power Cord away from heat, oil, sharp edges, or moving parts. Replace damaged Power Cords immediately. Damaged Power Cords increase the risk of electric shock.
- Disconnect the Power Cord before making any adjustments, changing accessories, or storing the Worklight. Such preventive safety measures reduce the risk of turning on the product accidentally.
- Never leave the Worklight unattended when it is plugged into an electrical outlet. Turn off the Worklight and unplug it from its electrical outlet before leaving the work area.
- People with pacemakers should consult their physician(s) before use.
 Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.

- 12. Do not operate the Worklight in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Electrical products create sparks which may ignite the dust or fumes.
- 13. Do not submerge in water or any other liquid.
- 14. WARNING: The cord of this product contains lead and/or di (2-ethylhexyl) phthalate (DEHP), chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm. Wash hands after handling. (California Health & Safety Code § 25249.5, et seq.)

15. Warning: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Assembly

- 1. Charge the Worklight before using it for the first time.
- Plug the AC/DC Adapter into the Worklight at its base. Plug the AC/DC Adapter to a 120V electrical outlet.



- Allow the Worklight to charge. Charging Indicator Light is the bottom LED bulb in center row. When Unit is charging, Charging Indicator Light will glow red. When Charging Indicator Light glows green, unit is fully charged. Disconnect the AC/DC Adapter.
- The Worklight also has a cigarette lighter adapter which can be plugged into a vehicle's cigarette lighter. Allow Batteries to charge. Disconnect the Adapter.

 To turn the Worklight on, press down on the On/Off Switch. To turn the Flashlight "OFF", press down on the opposite end of the On/Off Switch.



- The Cigarette Adapter contains one 250V, fast acting 3 Amp Fuse. To replace the Fuse, make certain the Adapter is unplugged. Open up the Cigarette Adapter, remove Fuse and insert new one. Close Cigarette Adapter.
- 7. The Worklight can be attached to metal work surfaces by placing its magnetic base against the metal portion of the work surface. The Worklight can also be hung by the Hanging Hook at its top. The Hanging Hook swivels 360 degrees.

Parts List

Part	Description	Qty.
1	AC/DC Adapter	1
2	Cigarette Adapter	1
3	Led Light	1
4	Fuse 250 V, Fast Acting 3 Amp	1
5	"S" Hanging Hook	2

Record Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed for illustration purposes only, and are not available individually as replacement parts.

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST IN THIS DOCUMENT AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES. EXPRESS OR IMPLIED. INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

