



# GRILL PARTS


For Models: KBNS361TSS00, KBSS361TSS00  
(Stainless Steel) (STLS w/Jacket)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	18	W10132690	Cover, Wire	38	W10132701	Flange (RT)
	W10110724	Use & Care Guide			Terminal	39	W10132697	Bracket, Flange
	W10110730	Conversion Instr. (LP to Natural)	19		Bushing	40	W10128777	Thermometer
2	W10128619	Cover, Rear		W10132691	Plastic (#SB22)	41	W10128779	Bezel, Thermometer
3	W10133863	Panel, Rear		W10132692	Plastic (#SB19)	42	W10128780	Insulator, Thermometer(Small)
4	W10133867	Panel, Access	20	W10133869	Outlet,Transformer	43	W10128782	Insulator, Thermometer(Large)
5	W10128634	Bracket, Panel Left	21	W10133876	Harness, Wire Light	44	W10133877	Handle, Hood
6	W10128635	Bracket, Panel Right	22	W10128664	Cover, Igniter	45	W10128785	Endcap, Handle (Left)
7	W10128636	Bracket, Warming Rack	23	W10128665	Igniter	46	W10128786	Spacer, Handle
8	W10128637	Cover, Access Panel	24	W10128751	Nameplate	47	W10128787	Endcap, Handle (Right)
9	W10128638	Clip, Wire	25	W10128753	Knob, Main Burner	48	W10128788	Hinge, Lid
10	W10133868	Hood Assy	26	W10128756	Knob, Rear Burner	49	W10133878	Hood
11	W10128640	Hole Plug	27	W10128759	Bezel, Knob	50	W10128715	Box, Battery
12	W10132699	Panel, Side Left	28	W10128761	Switch, Light	51	W10128711	Cover, Battery Box
13	W10128644	Bracket, Grease Tray (Right)	29	W10128762	Panel, Control	52	W10132698	Washer
14	W10128655	Roller, Drip Tray	30	W10128763	Harness, Wire Control	53	W10132696	Flange (LF)
15	W10133870	Drip Tray Assy (Includes Rollers)	31	W10128764	Valve, Main Brnr	54	W10132694	Brkt,Trnsfrmr(Top)
16	W10128657	Bracket, Grease Tray (Left)	32	W10128766	Valve, Rear Brnr	55	W10132695	Brkt,Trnsfrmr(Btm)
17	W10128669	Transformer	33	W10128767	Igniter, Main Gas	56	W10132702	Regulator (NG)
			34	W10133871	Manifold	57	W10128747	Fixture,Manifold
			35	W10133873	Baffle, Front	58	W10128748	Connector (Brass)
			36		Electrode	59	W10128749	Base, Manifold Fixture
				W10128770	Main Burner			
				W10133874	Main Burner			
				W10133875	Main Burner			
			37	W10132700	Side Panel, Right			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNERS, GRATES, AND LIGHTS PARTS

For Models: KBNS361TSS00, KBSS361TSS00  
(Stainless Steel) (STLS w/Jacket)



Illus. No.	Part No.	DESCRIPTION
1	W10133859	Rack, Warming
2	W10133860	Rack, Large
3	W10133862	Rack, Small
4	W10128618	Plate, Sear
5	W10128621	Electrode, Rear
6	W10128622	Thermocouple, Rear Burner
7	W10128623	Flex Tube, Rear Burner
8	W10133864	Burner, Rear
9	W10128625	Bracket, Rear Thermocouple
10	W10128626	Cover, Rear Thermocouple
11	W10128627	Orifice, Rear Burner
12	W10128628	Light, Grill
13	W10133866	Light, Grill(Set)
14	W10133865	Socket, Light
15	W10128704	Rod, Lighting
16	W10128703	Bag, Lighting Rod
17	W10128775	Burner, Main
18	W10128776	Bracket, Main Brnr

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: KBNS361TSS00, KBSS361TSS00  
(Stainless Steel) (STLS w/Jacket)

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>

## Miscellaneous

4396540	Altitude 2K-5K LP
4396541	Altitude 5K-8K LP
4396542	Altitude 8K-10K LP
4396544	Altitude 2K-5K NG
4396545	Altitude 5K-8K NG
4396546	Altitude 8K-10K NG
W10118099	Conv.Kit (NG-LP)
W10118098	Conv.Kit(LP-NG)
KBDU271TSS	Smoker Box
KFKU361TSS	36" Rotiss. Kit
W10136977	36" Insulated Jacket