

GminiTM XS 202

Pocket Music Player



Go for the music

ARCHOSTM

on the go



Gmini™ XS 202

Pocket Music Player

Gmini XS 202 series:
the smallest 20 GB* Pocket Music Player



- Autosync with Windows Media® Player 9 or 10: Easily transfer songs and playlists from your PC.
- Play MP3, WMA, WAV and protected WMA music files.
- Store up to 10 000 songs¹.
- Download protected music from multiple PlaysForSure™ websites.
- Rename, move, copy, and delete files or make playlists on the move without a computer thanks to the ARCHOS Browser.
- Quickly organize songs with the ARCHOS ARCLibrary and view by artist, album, title, genre, year or playlist (ID3 compatible).
- Connect to your stereo to play music (with optional standard audio cable).
- Easily navigate menus using the large and intuitive 2" LCD screen.




Technical features:

Capacity:	20GB* Hard Drive – store up to 10 000 songs ¹ .
Interfaces:	High-speed USB 2.0, compatible USB 1.1 (at a lower speed), PC & Mac.
Music playback:	Stereo MP3 decoding @ 30-320 kb/s CBR & VBR, WMA, WMA (protected WMA PlayForSure™ downloaded files) and WAV (PCM) - ID3 tag compatible.
Display:	Easily navigate menus using the large and intuitive 2" LCD screen.
Audio connections:	Stereo analog earphones/ Line Out jack.
Battery life:	Up to 17 hours ² .
Scalability:	Download firmware updates from www.archos.com
Power source:	Internal: Rechargeable Lithium-Ion Battery. AC Charger/Power Adapter.
Weight:	120 g (4.2 oz).
Minimum System Requirements:	Windows® ME, 2000 or XP - Mac OS v.10.2.4 - computer with USB 2.0 interface (compatible USB 1.1 at a lower speed). For protected WMA PlaysForSure™ downloaded files: require Windows® ME, 2000 or XP with Windows Media® Player 9 or 10.

Functionalities

- Rip or purchase :** Rip your CD collection into MP3 or WMA music files. Store up to 10 000 songs¹. Buy music content from legal online stores (protected WMA Playforsure™ downloaded files).
- Download :** Download all your music files (ripped or purchased) to your Gmini XS 202 using the high-speed USB 2.0
- Transfer :** Download and store data files from a PC or Mac.
- Organize :** Quickly organize songs with the ARCHOS ARCLibrary. View by artist, album, title, genre, year or playlists (ID3 tag compatible). Rename, move, copy and delete files or make playlists on the go without a computer thanks to the ARCHOS Browser.
- Play :** Click on music, select the file you want. Play MP3, WAV, WMA and (protected WMA PlayForSure™ downloaded files). Connect to your stereo with an optional standard audio cable. Easily navigate menus using the 2" LCD screen and intuitive icons.



More accessories are coming soon, please visit our website www.archos.com

*1 GB = 1 Billion bytes. Actual formatted capacity less.
1- On average. Music capacity based on 3.5 minutes per song and 64 kbits/s WMA encoding. For better quality, 128 kbits/s encoding or more recommended. 2- Calculated with included battery and based on audio use, battery life will vary with use.
All brands and product names are registered trademarks and the property of their respective owners. Specifications are subject to change without notice. Errors or omissions excepted. Images and illustrations may not always match contents. Copyright© 2005. ARCHOS. All rights reserved.