## Tanaka<sup>\*</sup>


# Parts Catalog

## Brushcutter

Model: TBC-262


All Units After Serial Number G 231370


#### FIG. 1 ENGINE



/	NER PARTIER	PARMANE	SERIA NER REMARKS
1-001 1-002 1-003 1-004 1-005 1-006	002-01601-800 018-00502-200 157-04000-900	CYLINDER COMP. SPARK PLUG BMGA SPARK PLUG CAP ASS'Y CYLINDER GASKET PISTON RING	
1-007 1-008 1-009 1-009 1-010 1-011	046-01620-801 046-01620-800 999-62081-225	PISTON PIN PISTON PIN CIRCLIP CRANK SHAFT COMP. CRANK SHAFT COMP. NEEDLE BEARING F-810 WOOD-RUFF KEY 3X13X4.5	
1-012 1-012 1-012 1-012 1-012 1-013	071-02007-210 071-02007-220 071-02007-230 071-02007-240	CRANK SHAFT SHIM 0.05 CRANK SHAFT SHIM 0.10 CRANK SHAFT SHIM 0.15 CRANK SHAFT SHIM 0.20 CRANK SHAFT SHIM 0.30 BALL BEARING #6002. 32MM/OD	V V V V V V V V V V V V V V V V V V V
1-014 1-015 1-016 1-017 1-018 1-019	999-66152-500 999-66122-266 090-00601-205 072-01620-900	BALL BEARING #6001, 28MM/OD OIL SEAL 15257 OIL SEAL 12227 CRANK CASE GASKET CRANK CASE ASS'Y CLUTCH WASHER B	
1-020 1-021 1-021 1-021 1-022 1-022	155-21720-800 155-21720-801 155-21720-802 165-01620-200	STARTER PULLEY MAGNETO ROTOR COMP. MAGNETO ROTOR COMP. MAGNETO ROTOR COMP. IGNITION COIL BRACKET IGNITION COIL BRACKET	1 R -D149567 1 R -E073890 1 E073891- 1 1 -F141220 1 F141221-
1-023 1-023 1-024 1-024 1-025 1-026	167-21507-802 904-01620-200 904-01620-201 894-01401-201	IGNITION COIL COMP. IGNITION COIL COMP ADJUSTER BRACKET ADJUSTER BRACKET OUTER RECEIVER IGNITOR COMP. TTI-1F	1
1-027 1-028 1-030 1-031 1-032 1-034	255-0608A-200 990-11050-161 992-10050-012 991-01080-011	S.WASHER 5	1 N D170956-
1-035 1-036 1-041 1-042 1-043 1-044	992-10080-012 991-01080-011 991-01060-013 990-11050-301 992-10050-012 990-11050-161	HEX. NUT 8 NUT 6 SCREW 5X30 S.WASHER 5	1 1 1 1 1 4 4 4 4 2 1 1 1 1 1 1 1 1 1 1
1-045 1-046 1-047 1-048 1-049 1-050	992-10050-012 990-11040-181 992-10040-012 992-00040-011 990-11040-081 992-10040-012	SCREW 4X18 S.WASHER 4 SMALL WASHER 4 SCREW 4X8	2 2 2 2 2 1 1
1-051 1-052	990-11050-121 992-10050-012		

#### FIG.2 ENGINE COMPONENTS






REF NBP PARTER	PARMANE	SERIA NER PENARAS
2-001 738-01620-200 2-001 738-01620-201 2-002 257-0630B-201 2-002 257-0630B-210 2-003 203-0630B-200	NUFFLER PROTECTOR HUFFLER PROTECTOR SPARK PLUG COVER SPARK PLUG COVER PRIMARY CORD GROWNET PRIMARY CORD GROWNET	1 R -D149567 D149568- 1 -D074939 1 P D074940- 1 -D074939 1 P D074940-
2-005   653-01620-200 2-007   655-06100-200 2-008   359-02103-200 2-009   290-01620-800	CYLINDER COVER COLLAR TANK BRACKET FUEL TANK CUSHION RUBBER CLUTCH WASHER B CLUTCH SHOE COMP. CLUTCH SPRING	1 1 4 2 2 2 1
2-014   289-01620-800 2-015   993-51032-002		2 2 1 1 1 1 1 2 1 1 2 1 1 2 1 1 1 2 1 1 1 1 2 1 1 1 1 2 1 1 1 1 2 1
2-018 2-019 2-020 2-020 198-01046-900 2-020 198-05015-800	STOP RING C-15 EX FAN CASE CLUTCH CASE CORD CLAMP ASS'Y CORD CLAMP COMP. ANTI-VIBE CASE A	1
2-022   599-01620-200 2-023   176-01620-200 2-024   539-01620-200	ANTI-VIBE CASE A CUSHION RUBBER EARTH TERHINAL ANTI-VIBE CASE B ANTI-VIBE CASE B HEAT SHIELD	F001501-  R -F001500 F001501-
2-027, 1 705-01620-902	HEAT SHIELD HEAT SHIELD NUFFLER GASKET	-D149567 1 M 1 N D149568- 1 N D149568- -D149567 D149568-
2-029, 1 717-01620-800 2-029 717-01620-810	MUFFLER COUPLING GASKET MUFFLER BODY B COMP. MUFFLER BODY B COMP. CUSHION RUBBER	1
2-034   404-01620-801 2-035   402-00601-202 2-036   700-03005-150	INLET MANIFOLD GASKET CARBURETOR INSULATOR COMP. CARBURETOR GASKET FUEL PIPE 3X5X150 RUBBER PIPE CAP RUBBER PIPE	
2-041   680-04019-210 2-041   680-00731-201 2-042   595-0062A-910	CLIP TANK CAP ASS Y, ORANGE TANK CAP ASS Y	
2-053	FUEL TANK STAND CUSHION RUBBER	1 R -D149567 1 D149568- 1 N E306501- 1 N E306501- 2 -E306500
2-057, 1 990-11040-161 2-057 994-15040-162 2-058 992-10040-012	SCREW 4X16/PS	2 M 2 N E306501- 2 D E306501-


REF NER PARNER	PARHAME	SERIN HER REMARKS
2-059 2-060,1 990-11050-221 2-060 994-15050-222	VASHER 4 SCREW 5X22	2 D E306501-
2-061 2-062 2-063.1 2-063 2-064 2-065 2-06	WASHER 5 SCREW 5X12 SCREW 5X12/PS S.WASHER 5	1 H H H H H H H H H H H H H H H H H H H
2-067   992-10060-012 2-068   990-31060-181 2-068   990-33060-181 2-069   990-21060-251 2-069   990-23060-221	BOLT 6X18 BOLT 6X18 BOLT 6X25	4 H H 2 H - G065501 G065502-
2-070	SCREW 5X12 S.WASHER 5 SHALL WASHER 5 S.WASHER 5	2 1 1 1 2 2 2 2 2
2-076 2-076 2-077,1 2-077,2 2-077 2-077 2-078,1 991-01050-011 990-23050-156 990-11040-121 994-13040-122 992-10050-012	U-NUT 5 BOLT 5X15 SCREW 4X12 SCREW 4X12/P	2 R -E244275 E244276- -D149567 2 N D149568- -D149567
2-078,2 2-078,2 2-078,2 2-078 2-079,1 2-079,1 2-079,1 2-080,1 992-01040-011 994-14060-152 990-51050-453	LOCK WASHER WASHER 4 SCREW 6X15/S HEX. HOLE BOLT 5X45	2 N D149568- 2 D D149568- 2 N -D149567 2 N D149568- 2 N D149568- 2 D149567
2-080 2-081.1 2-081 2-081 2-082 2-083 2-084 992-01040-012 992-01040-011 990-11050-161	SCREW 4X14 SCREW 4X14/PS S.WASHER 4 WASHER 4	2 N D149568-
2-085 2-086 2-087 2-087 2-088 2-088 2-089 2-090 2-090 2-01050-011 992-01050-011	SCREW 5X22 S.WASHER 5 SMALL WASHER 5 SCREW 5X10	4 2 2 2 2 1 N D149568- 1 N D149568-

#### FIG.3 AIR CLEANER




	NER PARTIER	PARTUANE		SERIANE	R REMARKS
3-000 3-000 3-001 3-001 3-002	410-0602D-900 AIR 410-0602D-901 AIR 424-0602K-200 AIR 424-0602K-201 AIR	CLEANER ASS'Y CLEANER CAP CLEANER CAP	1 1 1 1 1 1 1	R -D114148 D114149- R -D114148 D114149-	
3-002 3-003 3-004 3-005	446-0602K-200 CLE 453-0602K-200 SPAI 470-0602K-200 COL	CER	1 2		
3-006 3-006	423-0602K-200 CLE 423-0602K-210 CLE	ANER BODY	1 1 1	-D114148 D114149-	

#### FIG.4 RECOIL STARTER




REF	NER PARNER	PARTUANE	SERIANER REMARKS
4-000	762-01620-900	RECOIL STARTER BODY ASS'Y	1
4-001		RECOIL STARTER BODY	
4-002		STARTER ROPE REEL	
4-003	788-01250-200		
4-004		RECOIL SPRING	111.1
4-005	836-01250-200	FRICTION SPRING	1   N
ŀ	i ·		
4-005	836-06092-200	FRICTION SPRING	
4-006	837-01250-200	FRICTION PLATE	1   M
4-006	837-06092-200	FRICTION PLATE	11
4-007	832-01250-200	RETURN SPRING	11
4-008	990-15050-121	SCREW 5X12	11
4-009		ROPE 3.5X890L	līlml i
1 . 300			
4-009	783-06150-200	ROPE 3 588901	
4-009	783-0162V-200		i   "
4-010		STARTER HANDLE	111
4-011	780-06150-200		
4-012	1795-01620-200	HANDLE KNOB SEAL	


FIG.5 CARBURETOR



	-		
ak.k	NER PARTIER	PARNAME	SERIA NER REMARKS
5-000 5-001 5-002 5-003 5-004 5-005	455-25023-900 575-25010-200 577-25007-200 576-25006-200 475-25001-200	CARBURETOR ASS'Y WA-164	
5-006 5-006 5-007 5-008 5-008 5-008	476-25006-200 476-25004-200 464-25010-800 486-25006-200 486-25009-200	DIAPHRAGH COVER DIAPHRAGH COVER THROTTLE SHAFT COMP. THROTTLE SPRING THROTTLE SPRING THROTTLE SPRING THROTTLE VALVE	
5-009 5-010 5-011 5-012 5-013 5-014	488-25008-200 557-25006-200 460-25023-200 485-25003-200 461-25023-200	THROTTLE VALVE THROTTLE SHAFT CLIP HIGH ADJUST SCREW HIGH ADJUST SPRING LOW ADJUST SCREW HIGH/ŁOW ADJUST SPRING	
5-015 5-016 5-017 5-018 5-019 5-020	462-25006-200	IDLE ADJUST SCREW IDLE ADJUST SPRING VALVE SPRING NEEDLE VALVE VALVE HINGE	
5-021 5-021 5-022 5-022 5-023 5-023	578-25006-200 578-25007-200 539-25006-200 539-25008-200 489-25008-200 489-25008-200	INLET SCREEN SWIVEL SWIVEL STOP RING	1
5-024 5-024 5-025 5-026 5-027	548-25014-200 548-25012-200 514-25001-200 546-25001-200 467-25003-200	SET SCREW	5 M 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1


#### FIG.6 HANDLE






REF	NER PARNER	PARHAME	,	<b>€</b>	SERVA NER RET	MARKS
6-001 6-002 6-003 6-004 6-005 6-006	500-33560-200 343-37000-200 341-33560-801 347-33411-912 506-33560-200	HANDLE	1 1 1 5 1			
6-007 6-008 6-010 6-011,1 6-011,1	748-33564-900 504-33412-200 870-0062M-900 870-00741-900		1 1 1 1 1	H	E244276- -D149567 -E244275	
6-011 6-012 6-013 6-014 6-015 6-016	178-37003-800 183-01300-200 640-33905-200 883-33564-800	THROTTLE LEVER ASS'Y STOP CORD COMP. SWITCH NAME PLATE STOP BUTTON BRACKET THROTTLE LEVER BAND COMP. STOP SWITCH ASS'Y	1 1 1 1 1	N D D	E244276- D149568- D149568- D149568- D149568- D149568-	
6-017 6-018 6-019 6-020 6-021 6-022	990-11050-141 168-33905-201 178-0162R-800 991-01060-011 990-21060-451 991-01050-011	STOP BUTTON COVER STOP CORD COMP. NUT 6 BOLT 6X45	1 1 2 2 1	D D D	D149568- D149568- D149568-	
6-023 6-024 6-025 6-026 6-041 6-042	992-10060-012 992-01060-011 992-10050-012 990-11050-161 880-33564-200 832-33564-200	WASHER 6 S.WASHER 5 SCREW 5X16	2 2 1 1 1	H	D149568- D149568-	
6-043 6-043 6-043 6-044 6-045 8-046	176-33564-200	STOP SWITCH	1 1 1 1 1	N N N N	D149568- -E244275 E244276- D149568- D149568- D149568-	
6-047 6-048 6-049 6-049 6-049 6-050		SCREW 5X30 SCREW 5X30	2 2	N N N P N	D149568- D149568- D149568- -F141220 F141221- D149568-	
6-051		SELF-LOCK NUT 5		H	D149568-	

FIG.7 GEAR CASE




REF	NEP PARNER	PARTIAME	STY SERVANDER REMARKS
7-001.1 7-001 7-001 7-001 7-001 7-003.1	300-37000-900 300-37000-910 300-37000-910 300-37000-911 300-37000-912	GEAR CASE ASS'Y	1   -D149567 1   N -E244275 1   R -E244275 1   R -G230370 G230371- -D149567
7-003 7-003 7-003 7-003 7-004 7-005	300-33410-210 300-33410-210 300-33410-211 300-33410-212 302-37000-200 301-33411-200	GEAR CASE GEAR CASE GEAR CASE PINION	1 N -E244275 1 R -E244275 1 R -G230370 G230371-
7-006 7-007 7-008 7-008 7-009 7-009	999-61600-004 999-61600-003 999-61600-204	BALL BEARING #6000. 26MM/OD BALL BEARING #6000D, 26MM/OD BALL BEARING 6000D, 26MM/OD BALL BEARING #6002DD. 32MM/OD	1
7-010 7-011 7-012 7-013 7-014 7-015	993-50010-002 993-51026-002 324-33410-201 990-51050-203	STOP RING C-10 EX STOP RING C-26 IN	1 1 1 1 2 2 2 2
7-016 7-017 7-020,1 7-020 7-020 7-020	310-33410-202 310-33524-201 310-33524-201	OILING GASKET CUTTER HOLDER CUTTER HOLDER CUTTER HOLDER	2
7-021 7-022 7-023 7-024 7-029 7-030	992-29080-000 312-33411-200 992-01080-011 445-33578-200	TOOTHED LOCK WASHER 8 L/H CUTTER FIXING BOLT/L.H.T. WASHER 8 SAFETY GUARD HOLDER	1
7-030 7-031,1 7-031 7-031 7-031 7-032	441-33671-200 441-37003-800 441-37003-800 441-37003-801	SAFETY GUARD SAFETY GUARD COMP., METAL SAFETY GUARD COMP., METAL SAFETY GUARD COMP., METAL	D149568- -D149567 D149568- 1 R -E244275 E244276-
7-033 7-035 7-037 7-038 7-040 7-041	992-10060-012 990-11050-161 992-01050-011 992-10050-012 800-33005-201 990-11040-121	SCREW 5X16 WASHER 5 S.WASHER 5 CORD CUTTER BLADE	2
7-042 7-043	992-01040-011 799-33005-200		2 D D149568- 1 D D149568-

### FIG.8 TOOLS & NYLON HEAD



/.	NER PARTIER	&	SERVANDER REMARKS
8-000	783-33440-901	NYLON HEAD ASS'Y (TH-95X)	SERIANDER REMARKS
8-001 8-002 8-003 8-005 8-006	786-33004-801   789-33004-201   787-33004-202	CUTTING BODY COMP. BODY CAP CORD REEL 8X1.25 L/H BOLT (GOLD)	
8-007 8-008 8-009 8-010 8-011 8-021	673-35600-200 793-33440-200 358-02103-200	REEL SLIDER HOOK STEEL BALL 5/16" REEL SPRING (GOLD)	1
8-022,1 8-022 8-023 8-024 8-025 8-026	752-33900-200 813-20000-200 826-20000-200 951-20000-200	HEX. WRENCH 4 BOX SPANNER 17X19	1 N -D149567 1 N D149568- 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
8-027 8-028 8-030 8-032 8-033 8-034	540-33671-900 615-33411-900 615-33411-200	BOLT PROTECTION COVER GOGGLE ASS'Y CUTTER COVER ASS'Y	
8-035 8-035	948-32310-200 948-39907-200	TOOL BAG	1 I -G008000 G006001-
	:		
	į		

#### FIG.9 MARKS



9-003

9-004 9-005