Philips CD/DVD repair Kit





Repair your discs

Quickly repair minor scratches and repolish your discs with this repair kit. Our solution and repair cloth restores the surface of your discs. Suitable for CDs, DVDs and CD-ROMs.

Maintain original sound and video quality

- Quickly repair minor scratches and repolish discs
- Use over and over again
- Includes 10 Wipes
- Easy to use
- Simple operation as easy as playing a tape



Specifications

- Packaging dimensions
 Packaging dimensions (W x H x D): 12 x 9.25 x 2.25 inch
- Nett weight: 1.70311 lb
- Gross weight: 2.03965 lb
- Tare weight: .33654 lb

Outer Carton

- Gross weight: 8.32 lb
- Outer carton (L x W x H): 17.4 x 12.7 x 5.6 inch
- Nett weight: 6.81244 lb
- Tare weight: 1.50756 lb

JS2-P73020

Product highlights

Repair minor scratches

Specially formulated repair solution and repolishing cloth quickly repairs minor scratches to your CDs, DVDs and CD-ROMS.

Includes 10 Wipes

Includes 10 cloth wipes.

Simple operation

Simple operation as easy as playing a tape. Just apply fluid and "play".



Issue date 2008-08-17

© 2008 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 1.0.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 45275 UPC: 0 26616 01875 8

www.philips.com