

Table lamps
Operating instructions



Table lamp		
1.	Intended Use	4
2.	Technical Data	4
3.	Safety Instructions	4
4.	Operating elements	4
5.	Starting Up the Device	5
	Inserting the light bulb Setting up and switching on	5 5
6.	Cleaning and care	5
7. Disposal		5
8.	Service	5

Read the operating instructions carefully before using the appliance for the first time and preserve this booklet for later reference. Hand over the manual to anyone, whom you pass on the appliance to.

Table lamp

1. Intended Use

This table lamp is meant to be used in dry areas and indoors.

It is not intended for outdoor use and not for use in commercial or industrial areas.

2. Technical Data

Operating voltage: 220-240 V~, 50 Hz

Light bulb : 60 W - E27:

(Not included)

Maximum

power rating: 1 x 60 W

Protection class: II

3. Safety Instructions

To avoid life-threatening electric shocks:

- Only connect the table lamp to a power socket with a line voltage of 220-240 V ~, 50 Hz.
- Do not bend or squeeze the power cord.
- To disconnect, always pull out the plug at the power socket, do not pull at the power cord.
- Never use the table lamp in proximity of water or in damp cellar areas.
 Protect the table lamp from moisture and dirt.
- Before cleaning, or if there is a power supply fault, pull the plug out of the power socket.
- If the power cord is damaged, have it repaired by a qualified expert before using the table lamp again.

To prevent fire hazards and the risk of injury:

- Never touch the table lamp or the lamp shade while it is switched on. Make sure that the table lamp is switched off and has cooled down, before you touch it.
- While setting up the table lamp, make sure that it is at a minimum distance of 0.5 meters from illuminated objects.
- Never cover the lamp shade, and allow air to circulate freely around and inside the table lamp.
- Always place the table lamp on an even surface. Otherwise, it might tip over and cause fire.
- Never leave the table lamp unsupervised when in operation.

4. Operating elements

- Fastening ring
- 2 Lamp shade
- 3 Lamp socket
- **4** Power cord with cord switch



5. Starting Up the Device

Inserting the light bulb

⚠ Warning!:

- Always use a bulb of max. 60 W and E27 thread.
- Before inserting or replacing the lightbulb:
 - Switch off the table lamp,
 - pull out the plug from the power socket and
 - let the table lamp cool down completely.
- Screw the fastening ring 1 off the lamp socket 3.
- Place the lamp shade 2 with the small opening facing down onto the lamp socket 3.
- Screw the fastening ring 1 back onto the lamp socket 3 until the lamp shade 2 is firmly in place.
- Carefully screw the light bulb into the lamp socket 3. Make sure it is correctly screwed in.

The light bulb is not included in the package contents.

Setting up and switching on

- Place the table lamp on an even surface. Keep illuminated objects at a minimum distance of 0.5 m.
- Push the power plug into the power socket.
- Switch the table lamp on and off by means of the cord switch.

6. Cleaning and care

▲ Danger!

- Before cleaning the table lamp:
 - Switch off the table lamp,
 - pull out the plug from the power socket and
 - let the table lamp cool down completely.
- Never immerse the appliance in water or other liquids while cleaning.
- Clean the desk lamp with a dry, fluff-free cloth.
- Never use solvents for cleaning, to avoid damage to the tabel lamp.

7. Disposal

Never dispose off the table lamp with normal household waste. Contact your local town council or regional authority for information about how to dispose of the appliance in an appropriate, environmentally-friendly manner.

⚠ Warning!

Before disposing of the appliance, you can prevent accidents to children by detaching the power plug, thus rendering it unusable.

8. Service

® Kompernass Service United Kingdom Alpine House, Premier Business Park Long Street, Walsall West Midlands, WS2 9DY

Tel.:08707/876177 Fax:01922/725417

e-mail: support.uk@kompernass.com

(GB)

UK

ID No.: KH4063/4069/4070-06/05-V1