


Paper Shredder Destructeur de documents Destructora de documentos Aktenvernichter Papiervernietiger Distruggi documenti



**Operating Instructions** 

Mode d'emploi

Instrucciones de funcionamiento

Bedienungsanleitung

Bedieningsinstructies

Istruzioni sul funzionamento

Model:

S50 S70

P500 P700

## Safety Instructions

- · Read and save these instructions.
- · Follow all warnings and instructions marked on the product.
- Always turn off and unplug the machine before moving, cleaning, or conduct other than normal
  operation.
- Power cord should be easily accessible because it serves as the disconnect switch. If the power cord is damaged, call the number listed under Contact for Service.
- · Keep loose objects (jewelry, ties, long hair) away from shredder.
- CAUTION: Do not insert aerosol cleaners or lubricants into or around the machine. Some agents may
  combust, causing serious injury.
- · Empty wastebasket frequently.
- Do not place shredder near water, over a radiator or a heat register.
- Do not rest anything on the power cord. Do not place machine where people will walk on the cord.
- $\ensuremath{\bullet}$  The use of an extension cord is not recommended.
- Do not service this product yourself. An opened cover may expose you to dangerous voltage points or other risks, and will void manufacturer's warranty.
- Do not exceed recommended sheet capacity or usage. (See Sheet Capacity and Usage, Table A).
- Do not shred continuous forms.
- Do not shred labels, transparencies, glossy paper, newsprint, plastic or cardboard.
- Keep out of the reach of children and pets.
- Never insert your hand or fingers into feed opening.
- Practice caution when shredding paper that contains paper clips and staples. Shredder is intended for
  paper only. Although clips and staples will not harm the cutting system, the added thickness may
  decrease sheet capacity.

#### Installation

- Plug power cord into jack on the unit.
- Position shredder securely on basket.
- Plug power cord into a standard AC outlet with the appropriate power requirements as stated on the power supply.
- Follow instructions for sheet capacity. (See Table A)
- · Slide the power switch to the ON (I) position to activate the standby mode.
- · Shredder automatically starts when paper is placed in the entry and stops when finished shredding.

### Cleaning

- Unplug the unit from the wall before cleaning.
- · Housing can be cleaned with a cloth, dampened with a mild soap and water solution.

## Sheet Capacity and Usage

• Do not exceed recommended sheet capacity for your model.

Folding paper to fit the entry increases the thickness and recommended capacity may be exceeded.
 Clips and staples increase the thickness and may decrease sheet capacity.

	•	,		
	US 20# Paper	64 GSM	80 GSM	80 GSM
Model	Sheets per Pass	Sheets per Pass	Sheets per Pass	Sheets per Pass
	120V/50Hz	100V/50Hz	230V/50Hz	240V/50Hz
P500	5	5	5	5
S50	5	5	5	5
P700	7-9	7-9	7-9	7-9
S70	7-9	7-9	7-9	7.9

 Table A
 Different paper weights and electrical currents will affect capacity.

## Paper Jams

- 1. Immediately slide power switch to OFF (0) position.
- Slide power switch to the REVERSE (R) position until the jammed paper has been fully removed from the cutter.
- 3. DO NOT PULL ON PAPER. Damage to the drive system could occur.
- If the REVERSE (R) function will not operate, the internal overload protection device has been activated. Move the power switch to OFF (0). Wait 15 seconds and repeat.
- 5. If the machine jams in reverse, unplug the unit and cut all excess paper off the top and bottom of the machine before repeating the jam-clearing procedure.
- 6. Shred smaller quantities. See Sheet Capacity (Table A).

## **Specifications**

9" (230 mm)			
120V-60Hz (N. America)			
240V-50Hz (Australia)			
230V-50Hz (U.K., Europe)			
100V-50HZ (Japan)			
6 Feet (1.9 meters)			
1/4" (6.3mm) strip			

#### Recommended Daily Use 50-75

Model	Shredding Speed	<b>Dimensions</b>	<u>Weight</u>
P500/S50	14.8 fpm	14.5" x 13" x 7" 7.5 lbs.	
	4.5 mpm	369 x 330 x 178mm	3.4 kg
P700/S70	14.8 fpm	19″ x 15·1/2″ x 7·1/2″	7.5 lbs.
	4.5 mpm	483 x 394 x 191mm	3.4 kg

## Model S50/P500

When operating this product, you must use the enclosed power supply. Failure to do so will void the manufacturer's warranty and may damage the unit.

 60619
 North America

 60623
 Australia

 60621
 Europe

 60622
 Japan

 60620
 UK

### **Overload Protection**

This shredder is protected by a built-in thermal overload device that serves to protect the motor from overuse. When continuous shredding is conducted for an extended period of time, the shredder will automatically turn itself off to cool down. When shredding is automatically stopped, allow the unit to stand for about 30 minutes before using it again.

#### Important Note

This paper shredder is not intended to shred high volumes of paper. Please refer to the specifications for the recommended daily usage and sheet capacity of this shredder. Please note that if the paper is wider than the entry, and you fold it to fit, the paper thickness increases and the recommended capacity may be exceeded.

#### **Limited Warranty**

Fellowes Manufacturing Company warrants the cutting cylinders of all Fellowes shredders to be free from defects in material and workmanship for five years from the date of purchase by the original consumer. Fellowes warrants all other parts of the machine to be free of defects in material and workmanship for one year from the date of purchase by the original consumer. If any part is found to be defective during the warrant period, your sole and exclusive remedy will be repair or replacement, at Fellowes' option and expense, of the defective part.

This warranty does not apply in cases of abuse, mishandling or unauthorized repair. ANY IMPLIED WARRANTY, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS HEREBY LIMITED IN DURATION TO THE APPROPRIATE WARRANTY PERIOD SET FORTH ABOVE. In no event shall Fellowes be liable for any consequential or incidental damages attributable to this product. This warranty gives you specific legal rights. You may have other legal rights that vary from state to state.

For more detail or to obtain service under this warranty, please contact Fellowes Customer Service at 1-800-955-0959, Monday through Friday, 8 AM - 5 PM (Central Standard Time). For specific instructions on obtaining service under this warranty on machines purchased outside the USA, contact the appropriate location listed in the **Contact for Service** section of this instruction manual.

Warrantor: Fellowes Manufacturing Company.

## **Declaration of Conformity**

Fellowes Manufacturing Company

Performance

Doncaster Road, Kirk Sandall • Doncaster, South Yorkshire, DN31H England declares that the product Models S50/P500, S70/P700

conforms with the requirements of the Low Voltage Directive (73/23 EEC) and the Electromagnetic Compatibility Directive (89/336 EEC) and the following harmonized European Normes (EN Standards) and IEC Standards.

Safety: EN60950 'Information Technology Equipment'


EMC: Standard



Itasca, Illinois, USA March, 2000 Anthony Storrie

## Parts Identification

1. Power Jack4. Paper Entry2. Power Switch5. Wastebasket3. Housing



# Contact For Service Vos Contacts Fellowes Sus Contactos Fellowes Ihr Fellowes Kontakt Uw Fellowes Contacten Vostri Contatti Fellowes

77



1789 Norwood Avenue • Itasca, Illinois 60143-1095 630-893-1600 • Customer Service 1-800-955-0959 http://www.fellowes.com

Australia	Benelux	Canada	France	Germany	Italy	Japan	Poland	United Kingdom
Tullamarine, Vic	Vianen, NL	Markham, Ont.	Rennes, I-V	Garbsen, Han.	Camerano, AN	Tokyo	Warsaw	Doncaster, S. Yorks.

© 2000 Fellowes Printed in U.S.A. Form No. 32694