

# EASYSHARE M853 Zoom Digital Camera



[Features and Benefits](#)  
[Specifications](#)  
[M853 Accessories](#)

**Kodak**

Click on switch to view color (not all colors available in all countries)



## Enviably stylish—yours!

- 8.2 MP for prints up to 30 × 40 in. (76 × 102 cm)
- 3X optical zoom lens
- High ISO (up to 1250)
- Digital image stabilization
- HD still capture
- Choose from many stylish colors
- Li-Ion rechargeable battery included

## Essentials



### G610 Printer Dock

Stunning prints made one touch simple.



### SD 1 GB Card

Secure your pictures with the brand you trust.



### SD 512 MB Card

Secure your pictures with the brand you trust.

## M853 Support

Visit the [M853 Support Center](#). Find answers to your product and service questions. Find support bulletins, troubleshooting guides, software updates, and more.

[User manual](#)

[Tutorials](#)

[Frequently Asked Questions](#)

## Other Helpful Links

Discover how simple it is to shoot and share your digital photos.

[KODAK EASYSHARE System](#)

Making great prints from digital is easier than ever. Explore your options.

[Printing and Sharing](#)

Registered owners can choose to receive helpful tips, announcements, and exclusive offers.

[Register with Kodak](#)

[M853 Accessories](#)

## Amazing quality prints with 8.2 MP

8.2 MP means you can make stunning prints up to 30 × 40 in. (76 × 102 cm)

However you choose to print—at home, at retail, or online—trust Kodak for picture quality that's truly exceptional, and for memories that will last



## 3X optical zoom lens

The KODAK AF 3X Optical Aspheric Lens captures crisp details 3X optical zoom (35 mm equivalent: 37–111 mm) gets you closer to what's important without reducing image quality 5X continuous digital zoom gets you even closer



## Break the rules, not the bank

The M853 is simple to use and packed with the features you need to get great looking pictures. Plus, it's pocketable and available in stylish colors with optional fun accessories—all at a price you can afford.

### High ISO

Capture the details with faster shutter speeds when shooting under low light conditions with ISO up to 1250

### Digital image stabilization

Reduce blur caused by camera shake or subject movement

### HD still capture

View your pictures in high-definition on an HDTV or other HD device

### Customize your experience

Make a statement—pocketable with stylish colors and fun accessories to choose from including bags, skins, wrist and neck straps

Selectable sound themes available

### Show off your pictures

Get a good look at your pictures on the large 2.5 in. (6.4 cm)

### LCD

Whether you shoot your pictures vertically or horizontally, view them right side up with auto picture rotation

## KODAK PERFECT TOUCH Technology

Make your pictures as vivid as the moment you took them. Print better, brighter pictures using KODAK PERFECT TOUCH Technology.

Make better, brighter pictures

Relive your memories in richer detail

Clear up dark shadows to reveal more smiles

### Shoot video with ease

Record continuous VGA video (640 x 480) at 15 fps with sound and on-camera editing

Video print options include 1, 4, 9, and 16-up prints

Capture more video while using less memory with MPEG-4 compression

### Scene modes and picture enhancing features

Get a great shot time after time with 3 color modes and 17 scene modes, including sport, snow, beach, sunset, and more

Combine up to three shots into one large picture with on-camera panorama stitch mode

Easily create great shots with features such as on-camera cropping and blurry picture alert

### Internal memory plus

Don't miss a shot if your memory card becomes full – switch to in camera memory quickly, thanks to the internal memory plus feature

16 MB internal memory\* and SD/MMC card expansion slot let you start shooting right out of the box



## The simple way to share

The M853 is part of the KODAK EASYSHARE System, so sharing your pictures is amazingly simple. Just press Share.

### On-camera Share button

Sharing starts right on the back of the camera

Have a picture you want to share? Tag it using the exclusive on-camera Share button and it will be ready to print or e-mail later. Use the Favorites feature to keep special pictures close without filling up your internal memory.

### KODAK EASYSHARE Software (included)

The simplest way to find, create, and share.

The award-winning, elegant design makes your pictures the star of the show for a more enjoyable viewing experience.

English, French, and German photo card templates turn pictures into 4 x 6 in. (10 x 15 cm) announcements, invitations, holiday cards, and more, right at home.

Get more out of KODAK EASYSHARE Software with a variety of useful tips.

Use KODAK EASYSHARE Software to access your pictures at the KODAK Gallery—then view, edit, and save them to My Collection.

Automatically print better, brighter pictures, time after time, with KODAK PERFECT TOUCH Technology and our award-winning KODAK Printers and Printer Docks.

### KODAK EASYSHARE Camera Dock Series 3 (optional accessory)

Transfers your pictures and charges your battery at the touch of a button.

Instantly uploads pictures to your computer for viewing, printing, and e-mailing.

Charges your KODAK Camera Battery in less than 3.5 hours\*\* USB connection (USB 2.0 full speed compliant)



## Simple ways to print your pictures at home

Real KODAK Pictures are just a touch away with our convenient home printing options.

### KODAK EASYSHARE G610 Printer Dock (optional accessory, where available)

High quality, real KODAK Pictures with the touch of a button. Worry-free prints—get waterproof, fingerprint-proof, stain-resistant, wipeable prints that last a lifetime\*\*\* with KODAK XTRALIFE™ Lamination.

Transfer pictures to a computer at the touch of a button\*\*\*\*.

Get better, brighter pictures and red-eye reduction with automatic KODAK PERFECT TOUCH Technology.

Compatible with KODAK Color Cartridge & Photo Paper Kit / G.

### KODAK EASYSHARE G600 Printer Dock (optional accessory, where available)

High quality, real KODAK Pictures in just 60 seconds\*\*\*\*\* with the touch of a button.

Worry-free prints—get waterproof, fingerprint-proof, stain-resistant, wipeable prints that last a lifetime\*\*\* with KODAK XTRALIFE™ Lamination.

Clever design lets you take the fun with you for anytime, anywhere picture printing and sharing  
 Get better, brighter pictures and red-eye reduction with automatic KODAK PERFECT TOUCH Technology  
 Compatible with KODAK Color Cartridge & Photo Paper Kit / G  
**KODAK EASYSHARE Photo Printer 500 (optional accessory)**  
 Print real KODAK Pictures from digital media cards and USB devices, including PictBridge-enabled digital cameras  
 View and edit on the large 3.5 in. (8.9 cm) display  
 Works with or without a computer  
 Features KODAK PERFECT TOUCH Technology for better, brighter prints  
 Features red-eye reduction  
 Wireless capability (Wi-Fi ready\*\*\*\*\*, BLUETOOTH® Wireless Technology enabled)



**Ready to go—right out of the box**

Unpack the M853 and you're ready to shoot. It's that simple.

- KODAK EASYSHARE M853 Zoom Digital Camera
- KODAK Li-Ion Rechargeable Digital Camera Battery KLIC-7001
- 5V AC adapter
- USB cable
- Wrist strap
- Getting Started Guide with KODAK EASYSHARE Software
- Custom camera insert for optional KODAK EASYSHARE Camera and Printer Docks

\* 16 MB internal memory/11 MB available for picture storage (1 MB equals one million bytes).  
 \*\* Actual battery charging time may vary by camera model.  
 \*\*\* Under typical home display conditions.  
 \*\*\*\* Optional USB cable required.  
 \*\*\*\*\* Actual print speed may vary.  
 \*\*\*\*\* With the optional KODAK Wi-Fi® Card.



**This page contains:**

[Specifications](#)

[Package Contents](#)

[System Requirements](#)

# EASYSHARE M853 Zoom Digital Camera

## Specifications

### Standard features

|                  |   |
|------------------|---|
| Sensor type      | 1/2.5 in. CCD   |
| CCD total pixels | 8.3 MP (3320 × 2496)  |
| Effective pixels | 8.2 MP (3312 × 2488)  |
| Lens             | 37–111 mm (35 mm equiv.) f/2.8–f/5.2, mechanical shutter and ND4 filter   |
| Lens protection  | built-in  |
| Zoom             | 3X optical, 5.0X continuous advanced digital zoom, 0.2X increments starting at 3X optical zoom (LCD preview mode) |
| Shutter speed    | 4–1/1400 sec.   |
| LCD              | 2.5 in. (6.4 cm) high resolution (154k pixels) indoor/outdoor color display                                       |
| Storage          | 16 MB internal memory* available, SD/MMC card expansion slot  |

### Auto focus

|                  |  |
|------------------|--|
| Type             | TTL-AF, selectable: multi-zone (5 zones) AF, center zone AF  |
| Modes            | normal, landscape, macro selectable  |
| Focus range      | auto: 1.3 ft (0.4 m)–infinity<br>macro, wide: 5.9 in.–2.3 ft (0.15–0.70 m)<br>macro, tele: 1.3–2.3 ft (0.40–0.7 m)<br>landscape: 32.8 ft (10 m)–infinity |
| Auto focus       | yes  |
| Auto focus zones | multi-zone AF (5 point), center zone AF  |

### Exposure control

|                 |  |
|-----------------|--|
| ISO sensitivity | auto: 80-200; manual: 80, 100, 200, 400, 800, 1250 selectable  |
| Metering modes  | TTL-AE, center-weighted AE                                     |
| Compensation    | ±2.0 EV with 1/3 EV steps                                      |
| AE lock         | when S1 locked   |
| White balance   | auto, selectable (daylight, tungsten, fluorescent, open shade) |

### Flash

|       |   |
|-------|---|
| Range | wide: 2.0–11.5 ft (0.6–3.5 m) ISO 200<br>tele: 2.0–6.9 ft (0.6–2.1 m) ISO 200 |
| Modes | auto, red eye, fill, off  |

### Shooting specifications

|                  |   |
|------------------|---|
| Burst modes      | single shot, self timer (2 or 10 sec.), two-shots self-timer, burst 3 shot  |
| Shooting modes   | auto, SCN, video, Favorites, digital IS, high ISO, close-up   |
| Scene modes      | portrait, sports, landscape, children, night portrait, beach, snow, fireworks, self portrait, backlight, night landscape, text/document, manner/museum, flower, sunset, panorama, candlelight |
| Click to capture | < 0.4 sec. at > 1.6 ft (0.5 m), wide, preview on  |
| Shot to shot     | < 1.7 sec.  |

### Still capture

|              |                 |
|--------------|-----------------|
| Still format | JPEG/EXIF v2.21 |
|--------------|-----------------|

|                                |   |
|--------------------------------|---|
| Picture size                   | 8.1 MP (3296 × 2472)<br>7.2 MP (3296 × 2196)—3:2<br>6.1 MP (3296 × 1854)—16:9<br>5.0 MP (2592 × 1944)<br>3.1 MP (2048 × 1536)<br>2.2 MP (1800 × 1200)—3:2<br>2.1 MP (1920 × 1080)—16:9<br>1.2 MP (1280 × 960) |
| Color modes                    | color (high, natural, low), sepia, black and white  |
| Long time exposure             | 0.5–4 sec. (max)  |
| Review options                 | view by, album, edit picture, slideshow, multi-up, copy, protect, image storage, set-up   |
| Editing                        | KODAK PERFECT TOUCH Technology, on-camera crop, undo-delete   |
| <b>Video capture</b>           |   |
| Format                         | QUICKTIME video format, motion JPEG with audio recording during capture and playback  |
| Quality                        | VGA (640 × 480) at 15 fps, QVGA (320 × 240) at 30 fps   |
| Length                         | recording time: continuous based on memory capacity   |
| Review options                 | view by, action print, album, edit video, slideshow, multi-up, copy, protect, image storage, set-up   |
| Editing                        | make picture from video (1, 4, 9, 16-up), trim  |
| <b>Customization</b>           |   |
| Custom settings                | selectable sound themes, maintain settings  |
| <b>Sharing</b>                 |   |
| Favorites                      | slide show, multi-up, setup menu  |
| Share                          | print, print all, e-mail, Favorites, cancel print   |
| <b>Physical specifications</b> |   |
| I/O interface                  | A/V output (NTSC or PAL, user selectable), exclusive KODAK Camera Dock, digital (USB 2.0 full speed) connector  |
| Power                          | optional KODAK EASYSHARE Docks with Li-Ion Rechargeable Digital Camera Battery KLIC-7001, 5V AC adapter inlet on camera, USB charging via USB cable   |
| Dedicated buttons              | top: shutter, mode dial (Favorite, auto, digital IS, close-up, SCN, high ISO, video), flash setting, power<br>back: zoom, review, 5-way, Share, menu, delete, info  |
| Tripod mount                   | ¼ in. standard  |
| Dimensions                     | W × H × D: 3.7 × 2.9 × 0.9 in. (93 × 58 × 23 mm)  |
| Weight                         | without battery and memory card: 4.1 oz (115 g)   |
| <b>Compatibility</b>           |   |
| Dock compatibility             | <a href="#">See the Dock Compatibility Chart</a>  |
| Direct printing                | KODAK EASYSHARE Photo Printer 500, IMAGELINK print system compatible, PictBridge-enabled  |
| Software                       | works with KODAK EASYSHARE Software   |

## Package Contents

KODAK EASYSHARE M853 Zoom Digital Camera  
 KODAK Li-Ion Rechargeable Digital Camera Battery KLIC-7001  
 5V AC adapter  
 USB cable  
 Wrist strap  
 Getting Started Guide with KODAK EASYSHARE Software  
 Custom camera insert for optional KODAK EASYSHARE Camera and Printer Docks

## System Requirements

**WINDOWS**

**MACINTOSH**

**Hardware**

- WINDOWS XP OS or later
- INTERNET EXPLORER 6.0 or higher
- MACINTOSH OS X 10.3 or higher
- SAFARI 1.1 or higher
- 600 MHz processor or greater
- 128 MB RAM
- 200 MB hard drive disk space available
- CD-ROM drive
- Available USB port
- Color monitor, 800 × 600 display resolution, 16-bit minimum

\* 16 MB internal memory/11 MB available for picture storage (1 MB equals one million bytes).



# EASYSHARE M853 Zoom Digital Camera Accessories



KODAK Accessories are designed to help you get more from your picture taking experience.

Essentials

All Accessories



## EASYSARE G610 Printer Dock

Stunning prints made one touch simple.



## SD 1 GB Card

Secure your pictures with the brand you trust.



## SD 512 MB Card

Secure your pictures with the brand you trust.



## Li-Ion Rechargeable Battery KLIC-7001

The ideal choice for your camera's power.



## Li-Ion Universal Battery Charger Kit K7500-C

Charge your KODAK Li-Ion Camera Batteries anywhere.



## 5-Volt AC Adapter



## Cobalt Blue Camera Bag / Mini

Small, yet practical