

Microwave

FFCE2278L S



Signature Features

Sensor One-Touch Options

Microwave automatically adjusts power levels and cooking times to cook a variety of items, effortlessly.

Melt & Soften

Use the microwave to quickly melt or soften butter or cheeses for your recipes.

Keep Warm Setting

Keep food warm until everything—and everyone—is ready.

Easy-Set™ Start

Quickly start cooking—one to six minutes—with just one touch.

Countertop

Product Dimensions

Height	13-11/16"
Width	24"
Depth	21-3/8"

More Easy-To-Use Features

Ready-Select™ Controls

Easily select options with the touch of a button.

Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

Effortless™ Reheat

Reheat almost anything at the touch of a button.

Multi-Stage Cooking

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

Control Lock Option

Electronic Clock/Timer

Helps you keep track of cook times.

Attractive Stainless Steel Exterior

Interior Light

Illuminates the contents of the microwave for increased visibility.

Large Glass Turntable


Even large items fit on our large glass turntable.

Available in:



Stainless
(S)

Features	
Control/ Timing System	Ready-Select™
Exterior Door Finish	Stainless Steel
Handle Design	Push Button
Microwave Features	
Microwave Capacity (Cu.Ft.)	2.2
Watts (IEC-705 Test Procedure)	1,200
Interior Light	Yes
Interior Color	White
Turntable Diameter	16"
Turntable On/Off	Yes
Control Lock	Yes
Clock	Yes
Touch Pad Buttons	23
Power Levels	10
Accessory Metal Rack	
Microwave Control Options	
Easy-Set™ Start	Yes
Popcorn Button	Yes
Chicken Nugget Button	
Baked Potato Button	Yes
Sensor Reheat Button	Yes
Snack Button	
Beverage	Yes
Melt & Soften Options	4 / 4
Auto Reheat Options	
Snack Menu Options	
Auto Cook Options	
Auto Defrost Options	Yes
Keep Warm	Yes
Add-30-Seconds	Yes
Sensor Cooking Options	7
Vegetable Cook Sensor	Yes
Delay Start	
User Preferences	
Power Ratings	
Frequency (Mhz)	2,450
Watts @ 120 Volts	1,600
Amps @ 120 Volts	15
Specifications	
Oven Interior Height	11-1/8"
Oven Interior Width	17-1/16"
Oven Interior Depth	18-15/16"
Power Supply Connection Location	Rear
Voltage Rating	120V / 60Hz / 15A
Minimum Circuit Required (Amps)	15
Shipping Weight (Approx.)	51



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at frigidaire.com.



Product Dimensions ¹	
A - Height	13-11/16"
B - Width	24"
C - Depth	21-3/8"

¹A minimum clearance of 3 inches is required between microwave oven and adjacent walls. Leave a minimum clearance of 12 inches above microwave oven.

Accessories information available on the web at frigidaire.com

FRIGIDAIRE

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-800-FRIGIDAIRE • frigidaire.com
 CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • frigidaire.ca
 FFCE2278L 08/10

© 2010 Electrolux Home Products, Inc.

Specifications subject to change.
 Printed in the U.S.A.