


**AUDIOWOX<sup>®</sup>**  
ELECTRONICS CORP.

## Wireless RF Transmitter Installation Sheet



**CONNECT THE AUDIO OUTPUT OF THE FOLLOWING:**  
VOH641/642/681/682  
AVP7000/7180/7200/7280  
TO THE RED AND WHITE AUDIO INPUTS OF THE TRANSMITTER

**Channel Selection**  
Ch. 1 ..... 49.1MHz  
Ch. 2 ..... 49.7MHz