BRINKMANN®





MODEL 800-1700-0 OWNER'S MANUAL OPERATING INSTRUCTIONS

IMPORTANT SAFETY WARNINGS

READ AND FOLLOW ALL SAFETY WARNINGS AND INSTRUCTIONS IN THE OWNER'S MANUAL
 BEFORE OPERATING SPOTLIGHT.

WARNING

- Never place spotlight face down when light is on. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause serious property damage. Always turn spotlight off when not in use.
- To prevent serious damage to eyesight, never look into spotlight when light is on. Do not shine light into the face of someone else.
- Do not touch lens of spotlight when light is on or if it was recently on. The lens will be hot and could cause serious burns.
- Do not place spotlight in water. Keep all components dry and out of water at all times.
- Do not allow children to handle or operate this spotlight.
- Do not use this product for other than its intended use.
- Do not charge or operate in close proximity of combustible or flammable materials.
- Do not charge battery in gas tight enclosures.
- Do not attempt to charge or operate this spotlight if cord, plug, battery, charger, bulb or any part of the spotlight is damaged or corroded.
- Do not allow metal parts to touch metal contacts on battery as this can cause a short circuit and result in a fire.
- Do not use an outdoor AC outlet to recharge battery.
- Only use charging devices that are provided with this Q-Beam rechargeable spotlight or its replacements.
- Do not disassemble or tamper with the battery.
- Do not dispose of battery in fire as this may result in explosion.
- · When disposing of battery, place electrical tape over metal contacts on battery to prevent short circuit which could cause a fire.
- The sealed battery contains lead and must be recycled or disposed of properly. Contact your local county solid waste authority for proper recycling or disposal information.

USE CAUTION AND COMMON SENSE WHEN OPERATING YOUR RECHARGEABLE LIGHT.

FAILURE TO ADHERE TO THE SAFETY WARNINGS AND GUIDELINES IN THIS MANUAL COULD RESULT IN BODILY INJURY OR PROPERTY DAMAGE.

SAVE THIS MANUAL FOR FUTURE REFERENCE.

OPERATING INSTRUCTIONS

READ AND FOLLOW ALL SAFETY WARNINGS AND INSTRUCTIONS IN THE OWNER'S MANUAL BEFORE OPERATING SPOTLIGHT.

Inspect contents of the box to ensure all parts are included and undamaged.

Part List:

- (1) 12-volt DC Charger
- (2) AC Charger
- (3) Rechargeable Spotlight

Owner's Manual





- Step 1: Follow charging instructions below and allow battery to fully charge.
- Step 2: Depress trigger switch in handle to turn spotlight ON. Release trigger switch to turn spotlight OFF.
- **Step 3:** To lock trigger switch to ON, depress trigger switch and push in lock button on side of handle. To unlock and turn spotlight OFF, depress trigger switch and release.
- WARNING:

Never place spotlight face down when light is on. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause serious property damage. Always turn spotlight off when not in use.

- A fully charged battery will provide approximately 20 minutes of continuous light.
- Do not allow battery to completely discharge. A dim light indicates a low battery. Recharge battery as soon as possible after each use.
- Step 1: Make sure the trigger switch is NOT locked ON.
- **Step 2:** Plug the AC or DC charger into back of spotlight. Charging is indicated by illumination of the red L.E.D. light on left side of spotlight.
- **Step 3:** Allow battery to fully charge for at least 17 hours. Do not charge for more than 32 hours.

Only use Brinkmann's 6V 55W halogen bulb that is designed for this rechargeable spotlight as a replacement. Use of any other bulb may result in poor performance and may damage your spotlight.


- **IMPORTANT:** Do not touch the glass part of bulb with fingers as natural oils affect the life and performance of bulb. Handle bulb by metal end only.
- Step 1: Disconnect spotlight from power source.
- Step 2: Remove screws from right housing.
- **Step 3:** Holding the left housing secure, slowly lift the right housing off being careful not to pull wire connections inside. Do not touch the inside of reflector.
 - **NOTE:** The glass lens is not attached to either housing. Use care when disassembling to avoid breaking lens.
- **Step 4:** Push the wire retainer together and lift up as illustrated.
- **Step 5:** Pull bulb straight out from the reflector mounting plate.
- **Step 6:** Disconnect bulb wire from connector by holding the connector firmly with fingers then pulling bulb wire straight out.
- Step 7: To install new bulb, grasp the bulb from the metal end (DO NOT TOUCH THE GLASS PART) and insert into the reflector mounting plate.
- **Step 8:** Replace wire retainer by pushing ends together so they catch on the reflector mounting plate.


To Operate



To Charge

To Replace Bulb





Step 9: Reconnect the bulb wire to the connector.

Step 10: To reassemble, place the left housing down on a flat surface. Set the reflector into the left housing. Insert the right housing into the left housing of the spotlight.

Step 11: Replace screws that were removed in Step 2. Do not over tighten screws.

Replacement bulbs may be purchased from The Brinkmann Corporation Customer Service Department by calling 1-800-468-5252.

1-YEAR LIMITED WARRANTY

For 1-year from date of purchase, The Brinkmann Corporation warrants this Rechargeable Light against defects due to workmanship or materials to the original purchaser. The Brinkmann Corporation's obligations under this warranty are limited to the following guidelines:

- This warranty does not extend to the bulb or battery.
- This warranty does not cover rechargeable lights that have been altered or damaged due to: normal wear, abuse, improper
 maintenance, improper use, disassembly of parts and/or attempted repair by anyone other than an authorized employee of The
 Brinkmann Corporation.
- This warranty does not cover surface scratches or weathering as this is considered normal wear.
- Warranty service is limited to repair or replacement of rechargeable lights which prove defective under normal use and which
 upon examination shall indicate to Brinkmann's satisfaction, they are defective. If Brinkmann confirms the defect and approves
 the claim, Brinkmann will elect to repair or replace the rechargeable light as covered by the terms of this warranty.
- This warranty extends to the original purchaser only and is not transferable or assignable to subsequent purchasers.

The Brinkmann Corporation requires reasonable proof of purchase. Therefore, we strongly recommend that you retain your sales receipt or invoice. To obtain repair or replacement of your Rechargeable Light under the terms of this warranty, please call Customer Service Department at 1-800-527-0717 for a Return Authorization Number and further instructions. A receipt will be required. Rechargeable lights returned to Brinkmann must include your name, address and telephone number. Please make sure the light is properly packed, postage prepaid, and insured. A Return Authorization Number must be clearly marked on the outside of the box. Brinkmann cannot be responsible for any rechargeable lights forwarded to us without a Return Authorization Number.

EXCEPT AS ABOVE STATED, THE BRINKMANN CORPORATION MAKES NO OTHER EXPRESS WARRANTY.

THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO 1-YEAR FROM THE DATE OF PURCHASE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

ANY LIABILITY FOR INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING FROM THE FAILURE OF THIS RECHARGEABLE LIGHT TO COMPLY WITH THIS WARRANTY OR ANY IMPLIED WARRANTY IS EXCLUDED. CUSTOMER ACKNOWLEDGES THAT THE PURCHASE PRICE CHARGED IS BASED UPON THE LIMITATIONS CONTAINED IN THE WARRANTY SET OUT ABOVE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

140-1700-0 9/98 Owner's Manual for Model 800-1700-0