

Troika™ LED Desk Lamp

VD10



Dear Customer,

Thank you for purchasing the Troika™ LED Desk Lamp. You have received an innovative and quality manufactured product, backed by a one-year limited warranty.

Many other healthy lighting products are available through our catalog and online. To request a free copy of our catalog, call our toll-free number 1-888-544-4865. You may also visit us on the web at www.verilux.com to learn more about all our quality Verilux® products.

As a Verilux® customer, your satisfaction means everything to us. We look forward to serving you now and in the future.

Have a bright day!

Nicholas Harmon

President, Verilux, Inc.

Nicholas Harmon

Table of Contents

Warnings and Precautions
Features
Set-up Instructions
Operation
Care and Cleaning6
Technical Specifications
Troubleshooting
Warranty

Warnings and Precautions

- Please read these instructions before using this lamp.
- For indoor use only.
- Do not place near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- Do not block any ventilation openings.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where the power cord exits the lamp.
- Unplug this lamp during lightning storms or when unused for long periods.
- There are no user serviceable parts in this lamp. Do not dismantle. If the lamp
 has been damaged in any way, such as power cord or plug is damaged, liquid
 has been spilled or objects have fallen onto the lamp, the lamp has been
 exposed to rain or moisture, does not operate normally or has been dropped,
 it should not be operated.
- Lamp to be operated only with 100-240 VAC, 50/60Hz power.
- Avoid placing the lamp in areas that are dusty, humid/moist, lack ventilation or are subject to constant vibration.
- Not for use with light dimmers, timers, motion detectors, voltage transformers or extension cords.



WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR PERSONAL INJURY:

- Turn off/unplug before cleaning.
- Do not look directly at the lighted LED's without the diffuser being in place.
- Do not operate the lamp in close proximity to flammable or combustible vapors, such as aerosol spray products, or where oxygen is being administered.
- Never cover the lamp when it is in operation.
- To prevent risk of shock or personal injury when cleaning lamp, make sure you have turned off and unplugged the lamp.

SAVE THESE INSTRUCTIONS

Features

- Ultra energy efficient LED lamps help save up to 40% on electricity consumption.
- Flicker Elimination Technology® reduces eyestrain and fatigue.
- Optix® Filtering System provides glare-free and balanced illumination.
- Natural Spectrum® light improves color and clarity of reading materials.
- Lamp head adjusts 180° for precise placement of light or for discreet, ambient lighting.
- Built-in night light.

Set-up Instructions

What's included


Please remove all packaging material. Check the carton for the following items:

- LED lamp
- Power plug, cord and connector
- User manual

Introduction

Your new Troika™ LED Desk Lamp consists of:

- **1.** 3-position Switch
- 2. LED lights
- **3.** Arm
- 4. Base
- **5.** Power plug, cord and connector
- 6. Hinge




Operation

Instructions for use

- 1. Thread power cord through clips at the back of the lamp.
- 2. Plug connector into the receptacle on the lamp.
- 3. Place the lamp and position to proper angle.
- **4.** Slide the power switch to:
 - Solid orange spot: Off
 - Center (no spot): Nightlight
 - Orange open circle: On

Unplug the power connector if the lamp will not be used for long periods.



Care and Cleaning

Your Verilux® lamp is made from high quality materials that will last for many years with a minimum of care.

Clean only with a soft dry cloth – DO NOT USE SOLVENTS OR CLEANERS CONTAINING ABRASIVES OR AMMONIA.



WARNING: TO PREVENT RISK OF SHOCK OR PERSONAL INJURY WHEN CLEANING LAMP, MAKE SURE YOU HAVE TURNED OFF AND UNPLUGGED THE LAMP.

Technical Specifications

Troika™ LED Desk Lamp

Input voltage: 100-240 VAC, 50/60Hz

Output voltage: 12.8 VDC, 0.48A

Power consumption: 7 Watts (day mode); 0.25 Watts (night mode)

Operating temperature: 0°C – 40°C

Service lifetime: > 36,000 hours

Troubleshooting

Before requesting service on your Verilux® lamp, please read the following:

- Make sure all power plugs, cords and connectors are inserted fully and securely.
- Make sure there is power to the wall outlet or try another outlet.

CAUTION: Only use the power plug, cord and connector supplied with your Troika LED Desk Lamp. If other power plugs, cords or connectors are used, damage to your lamp may occur.

Problem	Check	Solution
	Has the power plug come loose from the wall outlet?	Insert plug securely into wall outlet.
Light won't come on.	Is the connector plug securely connected to lamp?	Be sure the connector plug is securely seated into the plug receptacle on the back side of the lamp.
Only one LED turns on.	Is the on/off switch pushed so that the orange open circle can be seen?	Be sure the switch is pushed all the way to the end until all LEDs are on.
Lamp arm does not stay in position.	Is hinge screw securely fastened?	Use screwdriver to tighten hinge screw.

One Year Limited Warranty

ATTENTION! ONCE OPENED, PLEASE **DO NOT** RETURN THIS PRODUCT TO THE STORE WHERE IT WAS PURCHASED FOR REPAIR OR REPLACEMENT!

Many questions may be answered by visiting www.verilux.com, or you may call our Customer Service Department at 802-496-3101 during normal business hours.

This limited warranty is provided by: Verilux, Inc., 340 Mad River Park, Waitsfield, VT 05673

Verilux warrants this product to be free from defects in material and workmanship for a period of one year from the date of the original retail purchase from Verilux or an authorized Verilux distributor. **Proof of purchase is required for all warranty claims.** During the limited warranty period, Verilux, Inc. will, at its option, repair or replace defective parts of this product, at no charge to the customer, subject to the following limitations: This limited warranty does not include any postage, freight, handling, insurance or delivery fees. This warranty does not cover damage, defect or failure caused by or resulting from accident, external destruction, alteration, modification, abuse, misuse or misapplication of this product.

This warranty does not cover damage to the product resulting from return shipping or handling. The use of shipping insurance is recommended to help protect your product.

Return Authorization is required for all returns. To obtain a Return Authorization, please contact the Verilux Customer Service Department at 802-496-3101.

If, during the first year of ownership, this product fails to operate properly, it should be returned as specified at www.verilux.com/warrantyreplacement or as instructed by a Verilux customer service representative at 802-496-3101.

Note: Verilux recommends using a quality surge suppressor on all electronics equipment. Voltage variations and spikes can damage electronic components in any system. A quality suppressor can eliminate the vast majority of failures attributed to surges and may be purchased at electronics stores.

Due to ongoing improvements, actual product may have slight variations from the product described in this manual.

Please visit our web site at: www.verilux.com



The Healthy Lighting Company® Est. 1956

340 Mad River Park, Waitsfield, VT 05673