
Refilling Instructions

for Hewlett-Packard 51641A Tri-Color Cartridge CONTENTS:








3 Refill Inks Cyan, Magenta, Yellow


ton Wipe Color Sequence Label

Remove ink cartridge from printer and protect work surface. Refilling your cartridge is a clean & simple job, but it is best to cover your work area with newspaper or paper towel to protect from accidental spills.

Your 51641A Tri-Color Cartridge







4. Tilt the cartridge forward so that you can insert the dispenser tip into the correct fill hole without dripping (Illustration 2).

Insert the dispensertip into the cartridge as far as it will go.






Illustration 2

Illustration 3

- **6.** Stop dispensing ink as soon as ink starts to overflow from the fill hole. Release the pressure from the bottle so that a small amount of the excess ink is drawn back into the bottle.
- . Remove the dispenser from the cartridge. Recap the dispenser and save for future use.
- 8. Use the cotton wipe to dry any overflow from around the fill hole.
- 9. Repeat the fill procedure with the other two colors so that all three ink chambers are topped off. There is no need to reseal the fill holes. Ink will not leak from them.

IF YOU HAVE ANY QUESTIONS OR ENCOUNTER ANY DIFFICULTY IN USING THIS PRODUCT, PLEASE CONTACT:



665 State Highway 23 • Wayne, NJ 07470-6892 U.S.A. • (973) 696-3330 • (800) 288-3330 Fax: (973) 694-7287 • Email: help@repeatotype.com

Hewlett-Packard is a trademark of Hewlett-Packard Company. ©1998 Repeat-O-Type Manufacturing Corporation.