



*ELITE Series*TM

PORTABLE GENERATORS

Illustrated Parts List

Las Partes ilustradas Listan

Questions? Help is just a moment away!
Preguntas? La ayuda es justa un momento lejos!
Call: **Generator Helpline**
Llame: **Línea Directa del Generador**
1-800-743-4115 M-F 8-5 CT
web: www.briggsandstratton.com

030208-1

(3500W)




BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.

Manual No. 199051A
Revision B (04/18/2006)



EXPLODED VIEW - MAIN UNIT





EXPLODED VIEW - PARTS LIST

Item	Part #	Description	Item	Part #	Description
1	M194779GS	CRADLE	40	194398GS	KIT, Fuel Tank Hardware (Includes Qty of 4)
2	194150GS	KIT, Vibration Mount	41	192980GS	KIT, Valve, Tank
3	*	TPHMS, M8 1.25 x 35	44	193645GS	ASSY, Tank, Fuel (Includes Items 41, 50, 51 & 52)
4	186058AGS	HOUSING, Engine Adapter	45	200095GS	CAP, Fuel
5	NSP	ASSY, Alternator (see page 4)	48	195373GS	WIRE, Ground
6	*	NUT, Hex, M8 - 1.25	50	188333GS	DECAL, Fuel Level
7	67989GS	NUT, M8 Flange Serrated	51	194799GS	DECAL, Danger
8	96796GS	WASHER, M8 Flat	52	189235GS	DECAL, Operating Instructions
9	*	WASHER, Lock M8	55	197798GS	DECAL, Fuel Shut Off
10	86307GS	HHCS, 5/16-24 x 3/4, SEMS	58	191743AGS	ASSY, Control Panel (see page 5)
11	24823GS	HHCS, 5/16-24 x 7-7/8" Lg	59	*	NUT, Nut, 3/16"
12	*	HHCS, M8 - 1.25 x 25	900	§	ENGINE
14	191785GS	BRACKET, Muffler			
15	697815	GASKET, Exhaust			
16	*	HHCS, M6 1.0 x 12 with LW			
17	188301GS	MUFFLER			
18	*	SHCS, M6 - 1.0 x 20			
19	83083GS	SCREEN, Spark Arrest			
20	B4986GS	DECAL, Ground			
22	86494GS	SCREW, Wing M6 - 1.0 x 16			
21	194153GS	KIT, Vibration Mount			
23	86292GS	SCREW, 10 - 16 x 3/4, Self Drill			
24	191790GS	SHIELD, Heat			
25	191190GS	CAP			
26	74908GS	TAPTITE, M5-0.8 x 10 Lg.			
31	196830GS	DECAL, Caution Hot Muffler			
34	195422GS	COVER, RBC with Cap			
35	195207GS	KIT, Fuel Hose with Clamp			
37	B2153GS	HHCS, 12 - 14 x 7/8" Self Driller			

Parts Not Illustrated

199051GS	MANUAL, Operator's
MS3430	MANUAL, Engine
BB3061GS	OIL BOTTLE
195576GS	KIT, Decals, Service
199384GS	DECAL, Family, CA EVP, 2006

Optional Accessories


100031	STABILIZER, Fuel
--------	------------------

§ - Contact Engine Manufacturer

* - Items without part numbers are common fasteners and are available at your local hardware store.




EXPLODED VIEW AND PARTS LIST - ALTERNATOR



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	191685GS	ROTOR (Includes Item 14)
3	191686AGS	STATOR
4	186060GS	RBC, with O-Ring (p/n 189197GS)
5	86308GS	HHCS, M6 - 1.0 x 115 SEMS
6	91825GS	ASSY, Holder, Rectifier/Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	22694GS	RECEPTACLE, 6 pin
9	81917GS	PIN, Roll, 4mm x 10
10	193428AGS	ASSY, Wire, Ground
13	194274GS	HARNESS, Wire, Power
14	65791GS	BEARING



EXPLODED VIEW AND PARTS LIST - CONTROL PANEL




Item	Part #	Description
1	195112GS	KIT, Cover Control Panel
2	188889AGS	CONTROL PANEL, Compact
6	68759GS	OUTLET, 120V, 20A, Duplex
7	*	NUT, Palnut, Pushnut, 5/32
8	84198GS	CAP, Breaker, Circuit
9	75207DGS	BREAKER, Circuit
10	68867GS	OUTLET, 120/240V Locking, 20A
11	*	NUT, Palnut, Pushnut, 3/16
12	*	PPPHS, M3 - 0.5 x 18
13	93857GS	BAR, Retaining
14	188890GS	COVER, Back, Control Panel
15	*	SCREW, 3 x 18, Tapping
16	22694GS	HOUSING, Receptacle
17	*	SCREW, 3.5 x 14, Tapping

* - Items without part numbers are common fasteners and are available at your local hardware store.



EXPLODED VIEW AND PARTS LIST - WHEEL KIT



Item	Part #	Description
1	189715GS	ASSY, Handle (Includes Item 11)
2	94034GS	LEG, Mounting
3	52858GS	NUT, Locking Hex M8 - 1.25
4	*	HHCS, M8 - 1.25 x 45
5	93728GS	AXLE
6	197061GS	WHEEL
7	87005AGS	PIN
8	*	WASHER, Flat M12
9	94222QGS	NUT, 5/8 - 18 Jam Lock
10	*	HHCS, M8 - 1.25 x 20
11	189718GS	GRIP, Handle

* - Items without part numbers are common fasteners and are available at your local hardware store.