

# iPod Touch Docking **POWER CASE Dock - Power - Play**

GENUINE LEATHER CASE WITH BUILT-IN RECHARGEABLE LITHIUM BATTERY FOR IPOD TOUCH

#### Item # IPT-PLC



Please read this manual carefully before operating and save it for future reference

## INTRODUCTION

The **PowerCase**™ is a multi-function product incorporating a rechargeable back-up battery, charger and carrying case. It is designed to fit and work with iPod Touch. When connected, the PowerCase™ will extend the video playback time up to 9 hours, music Playback up to 37 hours and internet use up to 10 hours. Keep the iPod Touch in the case to protect from dirt, scratches and for carrying.

## PowerCase™ Features & Benefits


- Durable and stylish fitted case.
- Easy access to all controls.
- Protect your iPod Touch against dirt, dust and scratches.
- Built-in high capacity rechargeable lithium polymer battery.
- Can be recharged over 500 times.
- Extends video and music playback time.

## 

- Charge the battery using only iPod Touch compatible cable and recommended iPod Touch charger.
- This battery is designed for use with iPod Touch only.
- Do not expose batteries to heat or fire.
- Never try to disassemble, modify or apply solder to battery.
- Never short the terminals of the battery or carry them together with metal objects that can cause shorting.
- · Never use, charge or store the battery in areas exposed to high temperature.

## PowerCase™ Charging Instructions

Connect the cable (supplied with your iPod Touch) to the *Power*-Case™ and to any USB port on your computer. The PowerCase™ may also be charged with a compatible AC adapter.



Turn the power on by using the ON/OFF switch at the side of the **PowerCase™**. The LED on the **PowerCase™** will light up RED and the internal battery will begin to charge.

When charging is complete the red LED will turn GREEN. Turn the switch to the off position when charge is complete.



## Charging the iPod Touch & Using the PowerCase™

Dock the iPod Touch in the *PowerCase™* Switch on the *PowerCase™* using the ON/OFF button on the side of the case. The iPod Touch battery meter will appear on the screen.

The LED will turn green indicating power is being generated to the iPod Touch. When fully charged, turn the switch to the OFF position. (If the LED does not turn on, there is not enough power to charge the iPod and the **PowerCase**<sup>TM</sup> must be recharged.)

You may continue using the iPod Touch while charging the battery.

Turn the power on by using the ON/OFF switch at the side of the PowerCase™. The LED on the PowerCase™ will light up RED and the internal battery will begin to charge.

When charging is complete the red LED will turn GREEN.

## **ONE YEAR WARRANTY:**

Mizco International, Inc., warrants this product to be free from defects in materials and workmanship to the original purchaser for a period of ONE YEAR from the original date of purchase. Mizco's responsibility with regard to this limited warranty shall be limited solely to the repair or replacement, at its own option, of any product, which fails during normal use. This warranty does not extend to damage or failure, which results from misuse, neglect, accident or alteration, abuse, improper installation, or improper maintenance. To exercise this limited warranty, send your name and address with proof of purchase and the UPC from this package. Product sent for warranty must be mailed to the address below, freight prepaid. Include \$5.00 for return shipping and handling.

#### **DIGIPOWER**

140 58th Street Bldg B, Unit 1F Brooklyn, NY 11220

E-mail: digipowersolutions@mizco.com © 2008 Mizco International, Inc. All rights reserved. Digipower is a registered trademark of Mizco Int'l, Inc. All trade names are trademarks of their respective manufacturers.