WARNING:

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture

CAUTION:

Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.



Power Consumption Power Source Antennas

Spe	aker

:	FM 87.5 - 108.5 mHz
	AM 525 - 1710 kHz
:	25W
1	AC 120V ~60Hz
:	External antenna for FM
:	Built-in ferrite bar for AM
:	4" dynamic type x 2
	, ,,

* DESIGN AND SPECIFICATION SUBJECT TO CHANGE WITHOUT NOTICE.

910-986100-025

IMPORTANT SAFETY INSTRUCTION


PLEASE READ CAREFULLY ALL THE FOLLOWING IMPORTANT SAFEGUARDS

- THAT ARE APPLICABLE TO YOUR EQUIPMENT
- Read Instructions All the safety and operating instructions should be read before the product is operated. Retain instructions The safety and operating instructions should be retained 1.
- 2
- 3 4
- 5
- 6.
- Retain instructions The safety and operating instructions should be retained for future reference. Heed Warnings All warnings on the product and in the operating Instructions should be adhered to. Follow Instructions All operating and use instructions should be followed. Cleaning Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning. Attachments Do not use attachments not recommended by the product manufacturer as they may cause hazards. Water and Moisture Do not use this product near water for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like. A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart 7
- 8. force, and uneven surfaces may cause the product and cart
- 9. Ventilation Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings should never be blocked or covered. The openings should never be blocked or covered. This product on a bed, sofa, rug, or other similar surface. This product or the manufacturer's instructions have been adhered to.
 10. Power Sources This product should be operated only from the type of power source indicated on the marking label, if you are not sure of the type of power supply to your home. Consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.



- bipping of the constant of the polarized active an event process, refer to the operating instructions.
 11. Grounding or Polarization This product may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet try reversing the plug, if the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
 12. Power Cord Protection Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.
 13. Lightning For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power line surges.





- Power Lines An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
 Overloading Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
 Object and Liquid Entry Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
 Servicing Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
 Damage Requiring Service Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions; a. When the power-supply cord or plug is damaged.

- - a. When the power-supply cord or plug is damaged.
 b. If liquid has been spilled, or objects have fallen into the product.
 c. If the product has been exposed to rain or water.

 - c. If the product has been exposed to rain or water.
 d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its
- all http:/pei.adjustment of other controls may result in contracts and the product to its normal operation.
 e. If the product has been dropped or damaged in any way.
 f. When the product exhibits a distinct change in performance this indicates a need for service.
 Replacement Parts When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
 Safety Check Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
 Wall or ceiling Mounting The product should be mounted to a wall or ceiling only as recommended by the manufacturer.
 Heat The product should be situated away from heat sources such as radiators.
- 20
- 21
- 22.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio TV technician for help