

LOOK INSIDE FOR: - EASY ASSEMBLY INSTRUCTIONS - IMPORTANT WARBANTY INFORMATION - SAFETY AND MAINTENANCE TIPS

NOTE:

HARDWARE SHOWN ACTUAL SIZE IN MANUAL.

> FOR YOUR CONVENIENCE, EXTRA HARDWARE MAY BE INCLUDED.

ASSEMBLER/INSTALLER: Leave these instructions with the consumer. CONSUMER/USER: Read all these instructions and keep them in

A SAFE PLACE FOR FUTURE REFERENCE.

TOOLS REQUIRED #2 Phillips Screwdriver


BOX END WRENCH








11412271 01/10


PLIERS HAMMER
















18 - P


2 LB LARGE HEAT SHIELD LEFT


EQ (0040 2481) #10-24 (2) Qty LB (3201 0219) #10-24 X 1/2" (1) Qty





(Pg. 9)





(Pg. 12)

LIMITED WARRANTY

Sunbeam Outdoor Cooking ("Sunbeam") warrants that this product will be free from defects in material and workmanship. This warranty applies to the following parts for the following time periods: the aluminum castings are warranted for a LIMITED LIFETIME against burn through; the burner is warranted for three (3) years; and all other parts are warranted for one (1) year, except the propane cylinder and paint finish. We DO NOT WARRANT in any way the propane cylinder (see label on cylinder for cylinder manufacturer's warranty) or the paint finish of the product. Sunbeam at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Sunbeam dealers, service centers, or retail stores selling Sunbeam products do not have the right to alter, modify or any way change the terms and conditions of this warranty. This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than Sunbeam or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

Sunbeam shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province. DO NOT RETURN THIS PRODUCT TO THE PLACE OF PURCHASE.

Take the product to an authorized Sunbeam service center. You can find the nearest authorized Sunbeam service center by calling I-800-641 -2100.

NOT VALID IN MEXICO.

For WARRANTY, Service and Parts Locate your model number and serial number on the label found on the back of your grill base.

BEFORE USING YOUR GRILL

Read Owner's USE and Care Manual:

- G For proper filling and purging of the cylinder
- G For leak testing all gas supply connections
- Given Structure For correct grill lighting instructions
- G For use and storage of the grill and cylinder

WARNING! The edges of sheet metal parts can cause injury if not handled with care. USE EXTREME CAUTION!

WARNING! WHEN LEAK TESTING:

DO NOT smoke.


DO NOT use fire to test for leaks,

△ DANGER:

NEVER store a spare LP gas supply cylinder under the grill body nor inside grill enclosure to avoid the possibility of an explosion. Refer to the Use and Care manual.

▲IMPORTANT:

Be sure to tighten up all hardware (screws, nuts, bolts, etc.) at least once a year or each grilling season.





ASSEMBLER/INSTALLER: Leave these instructions with the consumer.

CONSUMER/USER: Read all these instructions and keep them in a safe place for future reference.

IMPORTANT!! TO AVOID UNNECESSARY PROBLEMS! BEFORE YOU BEGIN:

Review this parts list with the parts in your carton. If you have missing or damaged parts, call this number IMMEDIATELY, 1-800-641-2100, for the SERVICE CENTER nearest you.

Montador / instalador: Deje estas instrucciones con el consumidor. Consumidor / usuario: Lea todas estas instrucciones y manténgalas en un lugar seguro como referencia.

i IMPORTANTE ! PARA EVITAR PROBLEMAS INNECESARIOS ANTES DE EMPEZAR:


Compare esta lista de piezas con las piezas que se encuentran dentro de la caja de cartón. En caso de que falten piezas o algunas estén en mal estado, llamar a este número INMEDIATAMENTE: 1-800-641-2100, para averiguar cuál es el CENTRO DE SERVICIO más cercano a usted.



11412271 01/10

Vari	LISTA DE PIEZASPARTS LIST				HARDWARE SHOWN ACTUAL SIZE	
Key <i>Réf.</i> Clave	Qty. Q <i>té.</i> Ctd.	Part# <i>N^o pièce</i> Parte #	DESCRIPTION	DESCRIPCION	LAS PIEZAS SE MUES	TRAN EN TAMANO REAL
1	2	0121 0435 01	STRAPS	BRIDAS DE SUJECIÓN	UN UL	6-9
3	1	0123 0148	AXLE	EJE	V	BF
4	2	0434 0128 01	LEG 1"	PATA 1"	(3201 0217)	(3270 0125)
9	6	1116 0115 09	SIDE TABLES	MESAS LATERALES	10-24 X 1/2"	
14	4	3023 0192	SIDE TABLE EXTENSIONS	EXTENSIONES DE MESA LATERAL	(11) Qty, Ctd.	(2) Qty, Ctd.
16	2	3022 0117	WHEEL	RUEDA		
17	2	0040 0251	HUB CAPS	TAPACUBOS	American	
18	2	3023 0231	LEG EXTENSION 1"	EXTENSIÓN DE PATA 1"	00 and 100	
25	1	0457 1030	CONTROL PANEL	PANEL DE CONTROL	V(3260 0102)	\land
26	1	0040 4437	IGNITER	IGNITOR	(6) Qty, Ctd.	
27	1	3517 0103	VALVE ASSEMBLY	SISTEMA DE VÁLVULA	(b) aty, ota.	
32	2	0040 4147	CONTROL KNOB	BOTÓN DE CONTROL	\frown	(0040 2481)
42	1	3412 0192 01	BOTTOM GRILL CASTING	BASE DEL ASADOR	LB	#10-24
43	1	3533 0114	BURNER	QUEMADOR		(4) Qty, Ctd.
45	1	3311 0122	COLLECTOR PLATE	PLACA RECOLECTORA	(3201 0219)	
47		1123 0169	LARGE HEAT SHIELD	PROTECTOR GRANDE DE CALOR	#10-24 X 1/2"	
48		3620 0134	ELECTRODE	ELECTRODO	(1) Qty, Ctd.	
48a	1	3290 0100	ELECTRODE SPRING	RESORTE DEL ELECTRODO		
49	1	3834 0137	GREASE CAN WIRE	ALAMBRE DE LATA PARA GRASA	Chamme.	wo((
55	1	3411 0324 01	GRILL LID	TAPA DEL ASADOR		
56		3421 0114	NAMEPLATE	PLACA ROTULADA	(0040 4422) 98-18 X 1/2	(0040 2507)
58	1	1116 0169 09	FRONT HANDLE	ASA FRONTAL		(2) Qty, Ctd.
60	2	3023 0183	STANDOFFS	SEPARADORES	(2) Qty, Ctd.	
61	1	0085 3001	ROCK GRATE	PARRILLA PARA PIEDRAS		\frown
62		3562 0121	CERAMIC BRIQUETTES	BRIQUETAS DE CERÁMICA		$\langle \rangle$
63	1	0416 0108	COOKING GRID	PARRILLA DE COCCIÓN		wн(())
65	1	3811 0174	WARMING RACK	REJILLA DE CALENTAMIENTO	(0040 4495)	$\langle \bigcirc \rangle$
78	1	3832 0117	CYLINDER WIRE	ALAMBRE DEL TANQUE	#10-24	
79	1	3551 0102	CYLINDER	TANQUE	(2) Qty, Ctd.	(3220 0106) (2) Qty
	<u> </u>		Λ	 WA		ск
				(0040 4468) (2) Otv	(3230 0112) (2) Qty, Ctd.	(3201 0189) #10-24 X 1 3/8"

2



(Pg.3)