# THE SHARPER IMAGE<sup>®</sup>

## FresherLonger™ Miracle Food Storage

**ZN020** Instructions



Read and save these instructions.

Dear Sharper Image Customer,

Thank you for your purchase of a Sharper Image product. We appreciate your business very much.

Our goal is that you will be completely satisfied with this product's quality and performance. We offer generous return privileges and excellent warranties on all our products.

Since 1977, The Sharper Image has shared the fun of discovering innovative products that make life better and more enjoyable. We've been in business a long time because we are an exciting place to shop and — just as importantly — we strive to deliver outstanding customer service that exceeds your expectations.

Enjoy your purchase!

Call 1-800-344-4444 for ordering and customer service, or visit www.sharperimage.com, our award-winning Website.

### Contents

The FresherLonger<sup>™</sup> Miracle Food Storage size assortment fits a wide variety of storage and preparation needs. The modular containers also work together to save valuable storage space.

### **Twelve-Piece Set Includes:**

- Two 44.0 oz. containers.
- Four 10.6 oz. containers.
- Two 28.2 oz. containers.
- Two 49.4 oz. containers.
- One 137.6 oz. container with removable interior tray.
- One 246.9 oz. container with removable interior tray.

The removable interior tray in the two largest FresherLonger containers is to allow water to drain from washed vegetables and fruits when they are placed in the container. The water will be under the tray, keeping the vegetables or fruits dryer.

### Features

Keeps Foods Fresher — Fruits, Vegetables, Herbs, Breads, Cheeses, Soups, Sauces & Meats!

### Airtight To Retard Spoilage!

Airtight silicone gasket locking system and impermeable polypropylene containers keep out oxidizing air.

### Spillproof & Shatterproof!

Extremely durable, heat-resistant polypropylene containers will not leak or break.

#### Dishwasher & Microwave Safe!

Still effective after dishwashing and microwaving. (Please open lid before microwaving.)

#### Freezer & Refrigerator Safe!

Practical containers can be used throughout your kitchen. Prevent freezer burn!

### Features

#### Save Money! Pays For Itself Fast!

End the expense, disappointment and frustration of tossing out costly food that has spoiled too quickly! Stop all those trips to the store!

#### Note On Exceptions.

Fresh mushrooms are not to be kept in food storage containers because they must breathe to maintain freshness. Imported bananas also stay fresh longer if they are not stored in food containers.

### Warranty

#### What Is Covered

This warranty covers any defects in materials or workmanship, with the exceptions stated below.

#### How Long Coverage Lasts

This warranty runs for 90 days from the date of original purchase.

#### What Is Not Covered

This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, or loss or damage to batteries or removable parts.

#### What The Sharper Image Will Do

The Sharper Image warrants this product against defects in materials and workmanship. When repair is not practical, The Sharper Image will have the option to replace the defective product with one that is the same or has similar functionality.

#### How to Obtain Service

Return the product and receipt, along with a brief explanation of the problem, to:

#### T.S.I. - Returns Department 2901-A West 60th Street Little Rock, AR 72209

If you have questions please feel free to contact our customer service representatives at 1-800-344-5555 or by email at care@web.sharperimage.com.

This warranty gives you specific legal rights, and you may have other legal rights that vary from state to state.

© 2006 Sharper Image Corporation

Sharper Image Corporation 350 The Embarcadero, Sixth Floor San Francisco, CA 94105-1218

#### Shop online: www.sharperimage.com

Actual product may differ slightly from the product described herein.

V2 09/06