

CD-7226 SONY Motion Detector Camera



Installation Manual

Covert High-Resolution Sony CCD
Indoor Motion Detector
Day/Night Spy Camera

Platinum CCTV Surveillance Solutions

CD-7226 SONY Motion Detector Camera	
Image Sensor	1/3" SONY CCD Sensor
Number of Pixels	NTSC: 568 (H) x 494 (V)
Lens	3.7mm Wideangle Pinhole
Sync System	Internal Synchronization
Resolution	420 TVL
Picture Area	4.9 x 3.7mm
Video Output	1.0Vp-p75Ω
S/N Ratio	More than 48 dB
Scan Frequency	60 Hz
Exposure	Automatic
White Balance	Automatic
Useable Illumination	0.05 Lux (F:1.2)
Power Source	DC 12V 90mA

Installation Notes

- For Indoor Use Only
- Disassembly of camera is not recommended
- Handle lens carefully with gloves to prevent damage from oil on your hands
- Handle with care
- To prevent shock, do not plug in camera with dome removed
- Never touch lens directly
- Clean the lens occasionally with a dry micro-fiber cloth, or plastic cleaner only – Do not use abrasive-type cleaners as they will scratch lens