

PCI-E Gigabit Ethernet Adapter RC401 User Manual

Key Features

Media Access Controller(MAC):

- 10/100/1000 Mbits/s triple-speed operation
- Compatible with IEEE® 802.3, 802.3u, 802.3x, 802.3ac, 802.1q, and VLAN
- IEEE 802.3x frame-based flow control
- PXE 2.0 support
- Wake on LAN

PCI Express Revision 1.0a Interface:

- Full compliance with Revision 1.0a
- Single-lane, 2.5 Gbits/s full-duplex channel
- Multiple traffic classes support
- Advanced error reporting
- 64-bit and 32-bit platform support
- End-to-end CRC(ECRC) support

Agere TruePHY technology

- 10Base-T/100Base-TX/1000Base-T gigabit Ethernet copper transceiver
- Automatic speed negotiation and downshift

Software:

- Windows® 2000, Windows® XP device drivers

Package Contents

- 1 x Gigabit Ethernet Adapter
- 1 x User Manual
- 1x Driver CD

Driver Installation

- 1. After the hardware is installed, turn on your PC. Windows® will detect the ET1310 Gigabit Ethernet Card and find a "Ethernet Controller" device. When Windows® asks "What do you want the wizard to do?", click the "Cancel" to cancel the driver installation for this device. This driver will be installed from the included Driver CD.
- Insert the Driver CD into the CD-ROM drive of your computer.
 Browse to the ET1310 Driver Folder "\LAN\ET1310\Windows" on the Driver CD, then double-click the installation file "Setup.exe". Follow the on-screen instructions to finish the driver installation.

Thank you for purchasing Rosewill Product.

Please register your product at www.rosewill.com for complete warranty information and future support for your product.