

Philips Cassette head cleaner

SAC2505W



Cleans cassette player

This cassette head cleaner uses non-abrasive cloth tape and special cleaning fluid to gently clean away dust, dirt and oxide build-up without damaging the audio heads and pinch rollers.

Maintain original sound quality

• Safe, wet cleaning system

Easy to use

• Simple operation as easy as playing a tape

Protect your cassette player

· Special cleaning fluid removes dust, dirt and oxide build-up



Cassette head cleaner

Specifications

Packaging dimensions

- Packaging dimensions (W x H x D): 4.25 x 7.75 x .75 inch
- Nett weight: .17 lbGross weight: .18 lb
- Tare weight: .01 lb

Outer Carton

- Outer carton (L \times W \times H): 4.75 \times 4.75 \times 8.5 inch
- Nett weight: 1.02 lb
- Gross weight: 2.381 lb
- Tare weight: 1.361 lb

SAC2505W/27

Product highlights

Special cleaning fluid

This cleaning fluid is specially formulated to gently clean away dirt, dust and oxide build-up. Works with the nonabrasive cloth tape.

Simple operation

Simple operation as easy as playing a tape. Just apply fluid and "play".

Wet cleaning system

Specially formulated cleaning fluid and non-abrasive cloth tape work together to thoroughly and safely clean away dust, dirt and oxide build-up.



Issue date 2008-08-19

© 2008 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 1.1.2

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 34791 UPC: 6 09585 14456 9

www.philips.com